

Projector Operation Guide

Multimedia Projector

EB-1925W EB-1915

TOP

Before Use

Precautions When Using the Wireless LAN Unit
Precautions on Handling and Storage
Precautions Regarding Frequency
Wireless Telegraphy Act Regulations
Precautions Regarding International Travel
Notes on Security when Using Wireless LANs
Wireless LAN Unit Specifications
Conditions for connecting to compatible Wireless LAN cards and access points
Specifications for this unit

Making Effective Use of Your Projector

Effective Functions for Projector Use
Various Screen and Audio Transfers by Network Connection (EasyMP Network Projection)
10Projecting directly from saved files on a USB device (PC Free).11Connect a USB Cable to Your Computer and Project Images from the ComputerScreen (USB Display).11
Installing the Software 12
Software Supplied. 12 Installing. 12

Connecting with EasyMP Network Projection

EasyMP Network Projection Summary	16
Two Connection Modes and their Main Functions	16
Advanced Connection Mode	16
Quick Connection Mode (Only when the supplied or optional Wireless LAN unit is installed)	16

Main functions	
Preparing to Connect	18
Preparing the Computer	. 18
Connecting to a Projector on a Network and Projecting	19
Operating the Projector.Operating the Computer.Using the Connection Screen.Using the Toolbar.	. 19 . 20

EasyMP Network Projection Useful Functions

Projecting Only a PowerPoint Slide Show (Presentation Mode)
Projecting Movies from a Computer (Movie Sending Mode) 27
Supported File Types
Playing Back a Movie
Using Multi-Screen Display 29
Example of Adjusting the Virtual Display
Procedure Before Using the Multi-screen Display Function
Setting the Virtual Display
Enable the virtual display driver (Windows only)
Adjusting the Virtual Display
Allocating the Image to be Projected
Projecting the Allocated Images

2



Connecting to a Projector on a Different Sub-net

Connecting to a Projector on a Different Subnet	38
Searching by Specifying the IP Address and Projector name (For Advanced Connection Mode only)	39
Performing a Search with a Profile	40
Making a Profile	. 41

Setting the EasyMP Network Projection Operation

Using Set options
Setting Each Item
General settings tab
Adjust performance tab
Audio Output tab

Using a Computer to Set Up, Monitor and Control Projectors

Changing Settings Using a Web Browser (Web Control) 49
Displaying Web Control
Entering the IP address of the projector
Projector Setup
Items in the Configuration menu that cannot be set by the web browser 49
Items that can only be set in the Web browser
Using the Mail Notification Function to Report Problems 51
Management Using SNMP 52

Presentations Using PC Free

Files that can be Projected Using PC Free
Specifications for Files that can be Projected Using PC Free
Supported movie files
PC Free Examples
Projecting images and movies stored on USB storage and so on
PC Free Basic Operations
Starting and Closing PC Free
Starting PC Free
Closing PC Free
PC Free Basic Operations
Rotating the Image
Projecting Scenarios
Creating and Editing a Scenario
Basic SIT file editing
Playing a Scenario
Operating During a Presentation
Projecting Image and Movie Files
Projecting Movies and Images
Projecting all Image and Movie Files in a Folder in Sequence (Slideshow) 63
Setting File Display Conditions and Slideshow Operations 64

Preparing a Scenario (Using EasyMP Slide Converter)

Scenario Summary
Converting PowerPoint Files to Scenarios
Convertible PowerPoint Files
Scenario Conversion Procedure
Explanation of the Main Screen
Converting to a Scenario

TOP	

4

Converting Directly from a PowerPoint File to a Scenario
--

Appendix

Connection Limitations	75
Supported Resolutions	. 75
Display Color	
Number of Connections	
Others	. 75
When Using Windows Vista	. 75
Limitations when projecting from Windows Photo Gallery.	. 75
Limitations in Windows Aero	. 76
Registering a Digital Certificate to the Projector	77
Registering a Client Certificate	. 77
Registering a CA Certificate	
Troubleshooting	79
Problems Concerning Network Functions	. 80
Cannot connect using EasyMP Network Projection.	
When a connection is made using EasyMP Network Projection, the projected	
image remains as it is, and a connection cannot be made from another computer.	
The projector is not found when EasyMP Network Projection is started	
Cannot connect in Advanced Connection Mode or Wired LAN connection	. 81
The Slide Show cannot be displayed on the desired display when the multi- screen display function is being executed	01
Applications are no longer displayed from the computer screen when the multi-	
screen display function is executed	
The mouse cursor is not displayed on the computer screen	
The image and sound for movies in EasyMP Network Projection are not displayed,	
the image is slow to appear, or either the video or audio stop	
No audio from the projector when connecting with EasyMP Network Projection	
When a connection is made using EasyMP Network Projection, a PowerPoint Slide	
Show cannot be started	
when a connection has been made using EasyMP Network Projection, the screen will not be refreshed when using an Office application	

Error message when starting up EasyMP Network Projection 8	84
Network settings are not restored after cutting the connection to the computer	~ ~
with EasyMP Network Projection	
Problems concerning PC Free	86
Cannot play back or display files in PC Free	86
Problems concerning EasyMP Slide Converter.	86
Error message when starting up EasyMP Slide Converter 8	86
"Convert to FSE" is not displayed in the PowerPoint right click menu 8	87
Problems Concerning Monitoring and Control.	87
Mail is not sent even if a problem occurs in the projector	87
Glossary	39
General Notes)0
General Notice:	90
Index)1



Before Use

Please read before using the supplied or optional Wireless LAN unit.



Note the following points when the supplied or optional Wireless LAN unit is installed in the projector and used.

To help you use the product safely and correctly, symbols are applied in the User's Guide and on the product to indicate possible harm to the user or to others and the risk of damage to property. The indications and their meaning are as follows. Make sure you understand them properly before reading the guide.

🕂 Warning	This symbol indicates information that, if ignored, could possibly result in death or personal injury due to incorrect handling.
A Caution	This symbol indicates information that, if ignored, could possibly result in personal injury or physical damage due to incorrect handling.

🕂 Warning

- May exert electromagnetic interference on, and cause malfunction of, cardiac pacemakers. Before use, ensure that electromagnetic interference does not occur.
- May exert electromagnetic interference on, and cause malfunction of, sensitive medical equipment. Before use, ensure that electromagnetic interference does not occur.
- Use of this product on aircraft may be restricted in some countries. Use of this product is based on due diligence with regard to regulations.

A Caution

- This unit should only be used with Epson projectors. If it is installed on a device such as a computer, it could result in computer failure, damage, or malfunction.
- Do not disassemble or remodel this unit. Otherwise you could be burned.

Precautions on Handling and Storage

- Do not store in locations with high temperatures or high humidity. In particular it may be damaged or deformed by leaving it in a vehicle with the windows shut, or placing it for extended periods in locations with unusually high temperatures such as in direct sunlight.
- Do not get it wet. This may cause malfunctions to occur.
- Do not use near microwave ovens. Wireless communication may be interrupted by the electromagnetic interference generated by microwave ovens.
- Do not drop it, subject it to impacts, or place heavy objects on it.

Precautions Regarding Frequency

The frequency band for this unit is 2.4 GHz/5 GHz. This band is used for industrial, scientific, and medical devices such as microwave ovens, and it is also used by the premises of a radio station for mobile unit identification (RF-ID) systems in the factory line (license required) and specified low-power radio stations (no license required). Before using this unit, check that there are no radio stations for mobile unit identification or specified low-power radio station premises nearby. In the event that this unit should interfere electromagnetically with the premises of a radio station used for mobile unit recognition, cease use immediately and stop generating the electromagnetic field. Contact your local dealer or the nearest address provided in the Support (see Epson Projector Contact List) if this unit interferes electromagnetically with a special low-power radio station used for mobile unit identification or causes similar problems.

Wireless Telegraphy Act Regulations

The following acts are prohibited by the Wireless Telegraphy Act.

• Modifying and disassembling (including the antenna)

- Removing the label of conformance
- IEEE 802.11a (5 GHz band) external use

Precautions Regarding International Travel

Wireless devices are designed to conform to the channel and frequency limits of the intended country of use. This unit is based on the specifications of the country of sale. If this unit is used outside the country of sale, check with a local dealer for more information.

Notes on Security when Using Wireless LANs

(Important information on customer rights (maintaining privacy))

The advantage of using a wireless LAN over a LAN cable is that, because information is exchanged using radio signals, you can easily connect to the network if you are within range of the radio signals. A disadvantage of this is that within a certain range, the electromagnetic signals can pass through barriers such as walls, so that if security countermeasures are not implemented in some way, problems such as the following may occur.

• Communicated data can be intercepted

A third party may be able to receive wireless transmissions without authorization, and they could obtain personal information from these transmissions such as IDs, passwords, or credit card numbers, or they could intercept the contents of personal e-mail messages. • Unauthorized access to the network

A third party could access an individual or intra-company network without permission and carry out any of the following activities.

- Retrieve personal data or other secret information (leaking information)
- Pose as another user and send inappropriate data (impersonation)
- Overwrite the contents of intercepted data and resend it (falsification)
- Introduce a computer virus which could cause data loss or system crashes (damage)

Initially, the possibility that such problems could occur through settings concerning the security of the wireless LAN product and by using the product are decreased, because the wireless LAN card and the access point have security measures to deal with these problems. We recommend that you use this product after making security settings using your own judgment and assuming full responsibility, and with your full understanding of problems that may occur if you do not make any security settings.

See the "User's Guide" on the "Document CD-ROM" supplied with the projector for more information on security settings.

Wireless LAN Unit Specifications

Conditions for connecting to compatible Wireless LAN cards and access points

This unit can be connected to the following products in accordance with IEEE 802.11g, 802.11b, and 802.11a.

- Wireless LAN card
- Computers with a built-in wireless LAN function
- Access points

TOP

However, you are unlikely to be able to make an ad hoc connection for wireless LAN equipment used with a computer in IEEE 802.11g. For more details on wireless LAN equipment see the specifications.

Specifications for this unit

Frequency band ^{*1}	IEEE 802.11b/g: 2.4 GHz band (1 to 11 Ch), IEEE 802.11a: 5.15 to 5.25 GHz (W52), 5.25 to 5.35 GHz (W53) ^{*2}
Modulation	IEEE 802.11b: DS-SS IEEE 802.11a/g: OFDM
Potential Interference Range	Less than 20 m
Propriety of Frequency Modulation	Can use all bands, and can avoid "licensed" and "unlicensed" bands.

 $^{\ast 1}$ You cannot use IEEE 802.11a in the People's Republic of China or the Russian Federation.

 *2 You can only connect to the W53 band using Advanced Connection.

TOP

8



Making Effective Use of Your Projector

This chapter provides information on functions that allow you to use your projector more effectively.

This projector is equipped with many useful functions to improve usability. As well as a computer cable, you can connect using various other interfaces such as a USB cable, a USB storage device, or a LAN connection. This allows for a wide range of image input sources depending on your usage environment.

Various Screen and Audio Transfers by Network Connection (EasyMP Network Projection)

You can hold efficient meetings and presentations by connecting the projector to a network.



Smooth progress

If the projector is connected to a network, you can share the projector from computers on the network. When projecting data from different computers during a meeting or presentation, you can progress smoothly without changing the signal cable between each computer.

Even a distance between the projector and the computer does not cause any problems.

Various screen and audio transfer functions

- Distribution function 🖝 p.16
- Switching function 🖝 p.16
- Multi-screen display 🖝 p.29
- Movie Sending Mode 🖝 p.27
- Presentation Mode 🖝 p.26

Monitor, Configure, and Control the Projector from a Remote Location

The following convenient functions collectively manage projectors in various conference rooms.

- Receive an e-mail notification if a problem occurs 🖝 p.51
- Monitor and detect problems from SNMP Manager on the network
 p.52
- Set and control the projector by using a standard computer Web browser (p.49

Project images from your computer using "Network Projector" in Windows Vista

In Windows Vista you can use the standard feature "Network Projector" to connect the projector to a computer via a network and then project. This lets you make presentations via a network by simply using a standard OS function without installing any software. User's Guide "Regarding Network Projector (EB-1925W/1915 only)"

TOP

TOP

Projecting directly from saved files on a USB device (PC Free)

By connecting a USB memory or a digital camera compatible with USB mass storage devices to the projector, you can directly project images, movies, and scenarios stored on the USB device. **p**.53

Connect a USB Cable to Your Computer and Project Images from the Computer Screen (USB Display)

By simply using the supplied USB cable to connect to a Windows computer, you can project images from the computer.

You can find the software for using the projector effectively on the supplied "EPSON Projector Software for Meeting & Presentation" CD-ROM. Install the software on the computer you are using.

The PC Free and USB Display functions are already built-in to the projector. They can be used as they are without being installed from the CD-ROM.

Software Supplied

You can find the following software on the "EPSON Projector Software for Meeting & Presentation" CD-ROM.

- EasyMP Network Projection Software for sending computer screen images to a projector via a network connection.
- EasyMP Slide Converter Software for converting PowerPoint files into scenario files that can be projected directly with PC Free.
- EasyMP Monitor

Software that lists the current status of Epson projectors connected to the network, and monitors and controls those projectors. You can collectively manage multiple projectors by using EasyMP Monitor. For details on using EasyMP Monitor, see the "EasyMP Monitor Operation Guide". *EasyMP Monitor Operation Guide*

Check the system requirements for each software application from Software Requirements in the "User's Guide" supplied with the projector. *User's Guide* "Software Requirements (EB-1925W/1920W/ 1915/1910/1830 only)"

Installing

Make sure you check the following points before starting installation.

- When using the following OS, you must have administrator authority to install EasyMP Network Projection.
 - Windows 2000
 Windows XP
 Windows Vista
- To install EasyMP Slide Converter, PowerPoint 2002 or later and Visual Basic for Applications (VBA) must be installed.
- When using the following OS, you must have administrator authority to install EasyMP Monitor.
 - Windows 2000 Windows NT4.0
 - Windows XP Windows Vista
- Make sure that you close all running applications before starting installation.
- When using Windows Vista, you must update to Windows Vista SP1 to use the Ukrainian version of EasyMP Monitor.
- When using Windows NT4.0, since Arabic and Hebrew are not supported, English is selected when installing EasyMP Monitor.
- When the language selected for the installation varies from that of the OS being used, the screens may not be displayed correctly.

TOP



. . .

• For EMP NS Connection users

The EMP NS Connection name has changed. Before: EMP NS Connection \rightarrow After: EasyMP Network Projection When using the same function as EMP NS Connection on the projector, install EasyMP Network Projection after uninstalling EMP NS Connection.You cannot connect to the projector correctly using EMP NS Connection.

• For EMP Monitor users

The EMP Monitor name has changed. Before: EMP Monitor \rightarrow After: EasyMP Monitor

If you are already using EMP Monitor, you can replace it with EasyMP Monitor. To update to EasyMP Monitor, uninstall EMP Monitor first, and then install EasyMP Monitor.

Procedure

For Windows



Turn on your computer.

Insert the "EPSON Projector Software for Meeting & Presentation" CD-ROM into the computer.

The installer starts automatically.

(3)

Click "Easy Install".

To select software and install it individually, select **Custom Install**. To change the language in which the software is displayed, click **Language**".



Check the applications to be installed, and then click "Install".

When the License Agreement screen is displayed, click "Yes".

6

When the Add-Remove EPSON Virtual Display screen is displayed, click "OK".

To use Multi-screen display you need to set up EPSON Virtual Display. If you do not want to set it up now, you can do so later. (-p), (-p)

7

Click "Exit" to complete the installation.

When EasyMP Slide Converter or EasyMP Monitor is selected, installation begins.

For Macintosh

EasyMP Slide Converter and EasyMP Monitor are not compatible with Macintosh computers.



Turn on your computer.

Insert the "EPSON Projector Software for Meeting & Presentation" CD-ROM into the computer.



Double-click the "ENPvx.xx_Installer" icon in the EPSON window.

Installation starts.

Click "Exit" to complete the installation.



14



• When installation does not start automatically (Windows only) Select **Start** - **Run**, and in the **Run** dialog box, type the letter for your CD-ROM drive followed by :\EPsetup.exe and then click **OK**.

• Uninstalling

For Windows

Select Start - Settings - Control Panel - Add-Remove Programs or Add or Remove Programs and then remove EasyMP Network Projection.

For Macintosh

From Applications, delete the EasyMP Network Projection folder.



Connecting with EasyMP Network Projection

This chapter explains how to connect the computer and the projector via a network, and the procedure for projecting images from your computer's screen with the projector.

There are two methods of connecting a computer and the projector via a network by using EasyMP Network Projection.

Two Connection Modes and their Main Functions

Advanced Connection Mode

Advanced Connection Mode is an infrastructure connection, and connects to an existing network system via a network cable. When connecting to a network via Wired LAN, connect the projector to the network hub with a commercially available LAN cable. If you install the supplied or optional Wireless LAN unit in the projector, you can connect to the network via a wireless LAN access point.



• You can monitor and control projectors on a network from the computer.

Quick Connection Mode (Only when the supplied or optional Wireless LAN unit is installed)

Quick Connection Mode only runs when you install the supplied or optional Wireless LAN unit in the projector.

Quick Connection Mode temporarily assigns the projector's SSID to a computer creating an <u>ad hoc</u> connection, and restores the computer's network settings after disconnecting. \bigcirc p.18



- You can easily connect to a computer and project images from the computer without making network settings.
- This lets you connect easily without a connector cable, and you can even connect if the projector and the computer are at remote locations.

Main functions

You can make meetings and presentations by using the following convenient functions.

TOP

TOP

17

• Multi-screen display 🖝 p.29

You can project different images from up to four projectors from one computer, allowing you to project landscape images such as spreadsheets and so on as one continuous image.



- Movie file transfer (Movie Sending Mode) p.27
 By using Movie Sending Mode, movies can be projected more smoothly than when being sent from an application running on a PC.
- Audio Transfer

You can play back by transferring the computer's audio to the projector on a one to one basis.

• Presentation Mode 🖝 p.26

This function can project a PowerPoint Slide Show running on a computer. You can give stylish presentations by projecting a black screen while making preparations and so on, and when not performing a Slide Show.

• Distribution function

The screen being displayed by a remote computer can be simultaneously displayed by up to four projectors on the same network. • Switching function

By using the meeting switching function, if EasyMP Network Projection is installed on all of the computers, the presenters can take turns and project their own images without changing cables.

Steps for Connecting

Use the following steps to connect the computer to the projector and project in EasyMP Network Projection.

You need to perform steps 1 to 4 only the first time you connect.

- 1. Install EasyMP Network Projection on the computer to be connected. (p.12
- 2.* Make network settings on the computer and put it into network connection status. (p.18
- 3. For Quick Connection Mode: Install the supplied or optional Wireless LAN unit in the projector (if already installed, go to step 5). For Advanced Connection Mode: Enable the Wired LAN adapter in "Port Configurations". ☞ Computer's documentation
- 4. Make network settings on the projector and put it into network connection status. ☞ User's Guide "Network Menu (for EB-1925W/1915)"
- 5. Start EasyMP Network Projection on the computer and connect with the projector. (p.19
- * When the computer you are using is normally connected to the network, you do not need to make network settings on the computer.

Use the following procedure to prepare the computer and the projector for connection.

Preparing the Computer

For Windows

Make network settings for the computer by using the utility software supplied with the LAN adapter. For more information on the utility software, see the User's Guide supplied with your LAN adapter. For example, as shown in the following illustration, when a red cross (\times) is displayed over the network icon on the taskbar, you cannot connect to the projector.



For Macintosh

Set the network port and communication status. For more details on setting the communication status, see the User's Guides for your computer or the AirPort card.

18

19

Operating the Projector

Before connecting, put the projector into connection standby status. Make sure the projector network settings are complete, and the projector is connected to network equipment such as a network hub via a commercially available network cable.

Procedure



Press the $[{\boldsymbol{\bigcup}}]$ button on the remote control to turn the power on.



Press the [LAN] button on the Remote Control.

The LAN standby screen is displayed.



Operating the Computer

In the following explanations, unless otherwise noted, Windows screen shots are used. You see the same screens even when using Macintosh.

Procedure



Select Start - Programs (or All Programs) - EPSON Projector - EasyMP Network Projection.

For Macintosh

Double-click the Applications folder of the hard drive volume in which EasyMP Network Projection is installed, and then double-click the EasyMP Network Projection icon.

Select "Quick Connection Mode" (Only when the supplied or optional Wireless LAN unit is installed) or "Advanced Connection Mode" and then click "OK".

The projector search results are displayed. To always connect using the same Connection Mode, select **Set the selected Connection Mode as the default mode for future connections.**

Select the projector you want to connect to, and then click "Connect".

If the projector you want to connect to is not displayed in the search results, click the **Automatic search** button. The search takes about 30 seconds.

For details on the connection screen, see "Using the Connection Screen". **•** p.20

When Projector keyword is set to "On" from the projector, the Keyword entry screen is displayed. Enter the keyword displayed on the LAN standby screen, and then click "OK".

When the connection is complete, the computer screen is projected. The following EasyMP Network Projection toolbar is displayed on the computer screen. You can use this toolbar to



operate the projector and make settings, and to disconnect the network connection. For details on using the toolbar, see "Using the Toolbar". \bigcirc p.22





When connecting from another computer, such as when changing presenters, start EasyMP Network Projection from the computer you want to connect. The computer that is currently connected is disconnected, and the projector is then connected with the computer that is trying to connect now.

Using the Connection Screen

Start EasyMP Network Projection to display the following screen. The operation of each button or item is described in the following table.





When the system starts in **Quick Connection Mode**.

	🔛 E	asyMP I	letwork P	rojection Ver.X.	🛠 – Quick Conr	ection -	
	Aut	J Automat	ic search	Manual search	Profile		
	Sel	ect a proje	ctor and conr	nect it.			
		Status		Projector name	SSID	Signal intensity	
			Standby	EMP02FAC1	EPSON1		
			Standby	EMP02FAC2	EPSON2		
5							
1							
7			- UI	pdate list	Save in the profile		Clear list
			errupt connec	tion			
		Jse multi-d	isplay			S	et options
		Trouble	eshooting			C	Connect

Auto

Automatic search

In Advanced Connection Mode, you can search for available projectors on the network system to which the computer is connected.

In "Quick Connection Mode", you can search for the projector based on the SSID.



Auto

0

Manual search

In Advanced Connection Mode, you can search for a projector based on a specified IP address or Projector name.

In Quick Connection Mode, you can search for the projector based on the SSID selected from a list.

Status

The following six icons indicate the status of the detected projectors.



Select for connecting.



Standby

Select for connecting. When you click **Connect**, the computer currently connected is disconnected and your computer is connected.

7	Busy (Disable interrupt con- nection)	Cannot be selected. Disable interrupt connection is set on another computer which is already connected.
	Currently in use by another application	The projector's Configuration Menu is open.You can select it after closing the Configuration menu and running the search again.
<u>.</u>	Searching	Displayed while running Manual search or Profile.
?	Not found.	Displayed when a projector cannot be found as a result of Manual search or Profile.In Quick Connection Mode, you can only select multiple projectors with the

4 Projector name

The projector's name is displayed.

(5) Disable interrupt connection

Check the box to prevent an interrupt connection by other computers while connected to the selected projector.

same SSID.

6 Use multi-display

Check the box to use the Multi-screen display function. When this is selected, Display layout and Display properties are displayed at the bottom of the screen. (-p.29)

Troubleshooting

If there is a problem and you cannot have a connection, press this button to open the EasyMP Network Projection Troubleshooting screen.

8 Connect

Connect to the projector you selected from the search results list. When a connection is made with a projector, a toolbar is displayed.

Set options

You can make general setting options such as the processing method when starting up EasyMP Network Projection. For details, see Set options 🖝 p.45

Save in the profile

Saves the results of a network projector search as a Profile. **••** p.40

TOP

22

Clear list

Deletes all search results.

- IP address (Advanced Connection Mode only) The projector's IP address is displayed.
- B Display

14

Select the number displayed (when Use multi-display is selected). 🖝 p.35

Profile

You can search for a projector on the network using a Profile saved using Save in the profile. $\textcircled{\begin{tabular}{ll} \bullet & p.40 \end{tabular}}$

- SSID (Quick Connection Mode only) The projector's SSID is displayed.
- **1** Signal intensity

This is displayed when the connection is made in Quick Connection Mode. As the Signal intensity increases, so does the number of lit indicators.

Update list (Quick Connection Mode only)

Updates Status and Signal intensity.

Using the Toolbar

The toolbar is displayed on the computer screen after EasyMP Network Projection starts and a connection is made with the projector. You can use this toolbar to operate and make settings for the projector.





Select target projector

Click to limit the projectors operated from the toolbar when projecting from multiple projectors using the distribution function or Multi-screen display. The indication below the icon shows the projectors that can be controlled.

ALL indicates that all of the connected projectors can be controlled. For example, when "1, 3" is displayed, projectors No. 1 and No. 3 can be controlled.

Click **T** to display the following screen.



① Select the projector to be controlled.

- 2 Indicates the No. of an allocated projector. This No. indicates the No. of the projector that you can control from the toolbar.
- ③ Indicates the status of the projector.



Stop



Show



Releases Stop or Pause.



Pause

Pauses projected images while connecting to the projector. Audio does not Pause.



Presentation Mode

Each time this is clicked, Presentation Mode switches between enabled/ disabled. **(p.26**)

Projector control

While the projector is connected to the network, the projector's A/V Mute, Switch PC source and Switch video source functions can be controlled from both the Remote Control and the projector's Control panel.







A/V Mute

The same function as the [A/V Mute] button on the Remote Control.

☞ User's Guide "Remote Control"



6 Switch PC source

The Source alternates between Computer1, Computer2, USB Display, USB1, USB2 and LAN each time you click.







Disconnect

.

Movie Sending Mode

Used to immediately play back a movie file. **•** p.27

Disconnect

Disconnects the connection to the projector.

Signal intensity

This is displayed when a connection is made in Quick Connection Mode. As the Signal intensity increases, so does the number of lit indicators.

Switch toolbar display

The Source alternates between S-Video, Video, and HDMI each time you click.S-Video does not switch if the cable is not connected.



Screen Preview

Displays the multi-screen preview screen.

Click 📕 to display a preview with the settings you have made.

Click the displays to enlarge each Screen Preview to full-screen.





Set options

Transmission performance during the transfer of computer images can be adjusted. **•** p.45





23



The toolbar display is switched as follows. The toolbar display remains as is until switched again.

Full



Normal



Simple





EasyMP Network Projection Useful Functions

This chapter explains those functions that may be useful during meetings or when making a presentation, such as the ability to send a movie file directly to a projector for playback (Movie Sending Mode) or that which allows you to send images to multiple projectors from a single computer (Multi-Screen Display).

In Presentation Mode, the images are only displayed when performing a PowerPoint Slide Show on a computer.When you stop Slide Show, the projector displays a black screen. This is useful when you only want to display the Slide Show.

In addition to PowerPoint, Keynote is compatible with Presentation Mode for Macintosh.

Procedure 1 If necessary, select another projector to be controlled. p.22 Click the button on the toolbar. Presentation Mode begins. Click the button again to exit Presentation Mode.

26

In Movie Sending Mode, movie files can be sent directly to a projector. As a result, a movie can be projected much more smoothly than when it is being sent from an application running on a PC.

Also, because the audio is sent at the same time as the movie, there is no need for an audio cable between the computer and the projector. You can set to play back selected multiple files repeatedly and in order.

- Movie Sending Mode is valid for one projector only.
- It is not possible to apply Movie Sending Mode to more than one projector.
- Depending on the communication method and the available reception, the image and sound may skip or stall.

Supported File Types

The file types supported by Movie Sending Mode are listed in the following table.

File Type (Exten- sion)	Video Codec	Audio Codec	Recording Quality
.mpg .mpeg	MPEG-2	MPEG-1 Layer1/2 MPEG contents with no sound can be played back. Linear PCM and AC-3 audio cannot be played back.	Highest frame rate: 30 fps Maximum reso- lution: 720×576
.mp4	MPEG-4 ASP MPEG-4 AVC	MPEG-4 AAC-LC	
.wmv .asf	WMV8 WMV9	WMA	

Files to which DRM (Digital Rights Management) is applied cannot be projected.

Playing Back a Movie





button on the toolbar.

The projector selection screen is displayed.

Select the projector you want to use to playback the movie and click "OK".

The Movie Sending Mode screen appears.

Click "Select file".

4ovie file list				Select file
Destination projector for N	fovie Sending	1	EBF1FF30	
Destination projector for N				00:00:00 / 00:00:00
				00:00:00 / 00:00:00



Select the movie file you want to play back and then click "Open".



The Movie Sending Mode screen reappears. The selected files are displayed in the Movie file list.

If you perform **Select file** again, the Movie file list changes after you make your selection.

5

Play and stop the movie files from the Movie Sending Mode screen.





Play Back Head

Drag & Drop to the point in the file where you want to start play back.



Plays back the file.

II Pause

Pauses play back.

Stop

Stops play back.

Back

Plays back from the beginning of the file that is playing.

▶ Next

14

Plays back from the beginning of the next file.

C Repeat

Repeatedly plays back the file list in order. When there are multiple files in the list, it is not possible to repeatedly play back only some of those files.

6) Click "Close" to end Movie Sending Mode.

88

TOP



Multi-screen display mode allows you to project different images from multiple projectors that are connected to a single computer.

With Windows, multiple <u>virtual display</u> drivers can be set in the computer, and each image can be projected by the projector. This function is not available with Windows Vista due to restrictions in the Windows Vista specifications.

For Macintosh, an external monitor must be connected to the computer to enable this function. While the following explanation refers to virtual display, for Macintosh the operation relates to the screens displayed on the physically connected monitor.



- Actual monitor image
- ② Image of virtual display1
- 3 Image of virtual display2

TOP

Example of Adjusting the Virtual Display

By arranging the <u>virtual display</u> allocation, you can project only the image that you want to show or project different images from left to right in a presentation.

Arrangement example 1



Actual monitor image

PowerPoint file Excel file

Image of virtual display

Arrangement example 2



Image of virtual display

PowerPoint file presenter tools Slide Show using a PowerPoint file

Procedure Before Using the Multi-screen Display Function

1. Setting the Virtual Display 🖝 p.31

In a Windows environment, enable the <u>virtual display</u> driver as necessary. And, for both Windows and Macintosh, set up the virtual display arrangement.

2. Allocating the image to be projected 🖝 p.35

ТОР

31

Open the file to be projected, and then move the screen to the virtual display according to the actual projection arrangement.

3. Projecting the allocated images 🖝 p.35

Allocate a virtual display number to a projector that is connected through the network, and then start projection.

Setting the Virtual Display

This section explains the virtual display for arrangement example 1. \bigcirc p.30

Enable the virtual display driver (Windows only)

Enable the <u>virtual display</u> driver. Those users listed below do not have to perform this operation. Go to procedure 🖝 "Adjusting the Virtual Display" p.31.

- Those users who have enabled virtual displays installing EasyMP Network Projection.
- For Macintosh users.

Procedure

Start Windows on the computer, then select "Start" -"Programs" (or "All Programs") - "EPSON Projector" -"Add-Remove EPSON Virtual Display".

The Add-Remove EPSON Virtual Display screen is displayed.

Select the virtual display you want to use.

Up to four monitors can be added. In this example, a single virtual display is to be used. When setting multiple virtual displays, select as many displays as is necessary. Any one of the displays can be selected.



When you click **OK**, the drivers for the virtual display are enabled. At this point, it is normal for the display to flicker. Wait for the Add-Remove EPSON Virtual Display screen to close.

Adjusting the Virtual Display

After starting EasyMP Network Projection, the setup of the virtual displays varies between Windows and Macintosh. The procedures are explained separately below.



Check the following points before starting EasyMP Network Projection when connecting via Wireless LAN. If the following points are not set correctly, Multi-screen display cannot be used.

- The SSID for the computer and each projector must be the same.
- The Wireless LAN system for the computer and each projector's Wireless LAN card must be the same. You can modify the SSID and Wireless LAN system for the projector from the Network menu in the projector's Configuration menu. User's Guide "Wireless LAN menu (Only

when the supplied or optional Wireless LAN unit is installed)"

Procedure

For Windows

Select "Start" - "Programs" (or "All Programs") - "EPSON Projector" - "EasyMP Network Projection" to start EasyMP **Network Projection.**

Select the "Use multi-display" check box.

🔛 E	asyMP Network	Projection Ver.X.	🗙 – Advanced Co	onnection – 📃 🗖 🔀
Auto	J Automatic search	Manual search	Profile •	
Sel	ect a projector and co	nnect it.		
	Status	Projector name	IP address	Display
	💷 Standby	EMP02FAC1	192.168.11.1	1 👻
	📷 Standby	EMP02FAC2	192.168.11.2	3 🗸
			Save in the profile	Clear list
	Disable interrupt conn Use multi-display	ectioni		Set options
	Troubleshooting			Connect
Disp	olay layout			
		1	2 3	
				Display properties

Display layout and Display properties are added at the bottom of the screen.



Update list Save in the profile Clear list Disable interrupt connection 🔽 Use multi-display Set options Connect Troubleshooting Display layout 3 Display properties

The Display Properties screen is displayed.

Click the "Settings" tab.



88



Drag the displayed monitor icon and place it where desired.

Here, the actual monitor (1) is placed on the left, while the virtual monitor (3) is placed on the right.

When the computer has multiple display output terminals, the numbers assigned to the virtual terminals will be sequential to those of the physical terminals.

Display Propertie	s			? 🛛
Themes Desktop	Screen Saver	Appearance	Settings	
Drag the monitor ic	ons to match the	e physical arran	gement of y	your monitors.
		3	2	
		ປ 📗	_	
		(
Display: 1. Plug and Play N	fonitor on NVIDI	A GeForce 620	10 TurboCa	che(TM) 🔽
Less	More	Highest	-	~
1280 by 10	Y 124 nixels			
Use this device	•	ponitor		
	dows desktop or			
	Identify	Troublesh	oot	Advanced
	Identity			Advanced
		ок	Cancel	Apply



- When an external monitor is connected as a secondary monitor, the image for that screen cannot be projected.
- Depending on the hardware, the number of the secondary monitor may be other than "2". When the monitor icon is displayed on the screen, click the icon and confirm that the monitor type shown under "Display" is other than "secondary".
- For Screen Resolution settings, see the following. P.75

When the monitor icon is arranged, a virtual display is connected as the image like below.





Click the "OK" button. The Display Properties screen closes.

Up to this point, the virtual display layout has been fixed. Allocate the projecting images next. \bigcirc p.35

For Macintosh

Start EasyMP Network Projection. Double-click the Applications folder of the hard drive volume in which EasyMP Network Projection is installed, and then double-click the EasyMP Network Projection icon.

Select Advanced Connection Mode and then perform startup.

Select the "Use multi-display" check box.

automatic search	Manual search	n Profile	•	
ect a projector and co	onnect it.			
Status	Projector name	IP address		
Standby	EPSON-PJ	192.168.100.110		
		Save in the pro	ofile	Clear list
	rection		_	Set options
	nection			Set option
Disable interrupt conr Use multi-display				Set options

Display layout and Display preferences are added at the bottom of the screen.



Click "Display preferences".

Automatic search	Manual search	Profile	•	
lect a projector and	connect it.			
Status	Projector name	IP address	Display	
💽 📷 Standby	EPSON-PJ	192.168.100.110	2 ‡	
		Save in the pro	ofile	Clear list
Disable interrupt con Use multi-display	inection	Save in the pro	ofile	Clear list Set options
	inection	Save in the pro		
	inection	Save in the pro		Set options

The display setting screen is displayed.



Click "Arrangement".

Show All	DELL E2009W
	Display Arrangement Color
Resolutions:	
640 x 480	Colors: Millions
800 x 500	
800 × 600	Refresh Rate: 60 Hertz
848 x 480	Detect Displays
1024 x 640 1024 x 768	Gather Windows
1152 x 864	Gather Windows
1152 x 870	Rotate: Standard
1280 x 720	
1280 x 800	Show displays in menu bar
Clear "Mirror D	isplays".
Clear "Mirror D	DELL E2009W
00	DELL E2009W
O Show All	DELL E2009W
O Show All	DELL E2009W
Show All	DELL E2009W
Show All	DELL E2009W
Show All	DELL E2009W
Show All	DELL E2009W
Show All	DELL E2009W

6 Dra

Drag the displayed monitor icon and place it where desired.

TOP

OOShow All	Color LCD	Q
	Display Arrangement Color } g them to the desired position. a it to a different display.	
Mirror Displays		(?)



Close the display setting screen.

Up to this point, the screen layout has been fixed.

Allocating the Image to be Projected

This section explains the virtual display for arrangement example 1. (-p) = p = 0.30

Procedure

Open the file to be projected.

Start the PowerPoint and Excel files.

Drag the window to the desired <u>virtual display</u> monitor, and allocate it where the image is to be projected.

Drag the Excel window to the right until it cannot be seen. As a result, the PowerPoint window appears on the actual monitor, while the Excel window appears on the virtual display on the right.



Projecting the Allocated Images

This section explains the virtual display for arrangement example 1. \rightarrow p.30

Procedure

Select the number of the <u>virtual display</u>[▶] to allocate on the "Display", and set which image to be projected from which projector.

🖉 EasyMP Network Projection Ver.XXX - Advanced Connection - 💦 🗖 🗙						
Automatic search	Manual search	Profile 🝷				
Select a projector and connect it.						
Status	Projector name	IP address	Display			
🗹 💽 Standby	EMP02FAC1	192.168.11.1	1			
🗹 💽 Standby	EMP02FAC2	192.168.11.2	3 🔍			
\checkmark			\smile			



Click "Connect".





The image allocated to each projector is projected.



To perform mouse-based operations on the virtual display, move the mouse pointer in the direction of the virtual display, such that the pointer appears on the virtual display.

To terminate multi-screen display, click "Disconnect" on the toolbar.

- In a Windows environment, if the virtual display driver has been enabled such that the mouse pointer can be moved outside the limits of the screen, there may be occasions when you lose track of the location of the pointer. When you are not using a virtual display, clear the check mark against the virtual display under Add-Remove EPSON Virtual Display, so that the mouse pointer cannot be moved outside the limits of the screen. To subsequently use multi-display again, place a check mark against the required display under Add-Remove EPSON Virtual Display. To clear a check mark, see the following. p.31
 - You can adjust each projector's color tone. User's Guide "Correcting Color for Multiple Projectors (Multi-Screen Color Adjustment)"

In a Windows environment, you cannot view the image being sent to a virtual display on the computer. To adjust the image on the virtual display, you must do so while viewing the projected image.


Connecting to a Projector on a Different Sub-net

This chapter explains how to connect a computer to a projector on a different sub-net via a Wired LAN or a wireless LAN access point on an existing network system.

By default, this application only searches for projectors on the same subnet as the computer. Therefore, even if you perform a search for projectors on the network, projectors on a different subnet will not be found.

You can, however, identify and connect to a projector on a different subnet as follows:

- Specify either an IP address or Projector name and perform a search. The IP Address can be input directly. Also, provided the Projector name to be connected has been registered on the DNS server, you can perform a search simply by inputting that Projector name.

 p.39
- Performing a search based on a Profile

Once you have performed a search for a projector on a different subnet by specifying either an IP Address or a Projector name, you can save the search as a Profile with an easy-to-remember name, and then use that Profile whenever you subsequently want to search for a projector on a different subnet. $rac{1}{2}$ p.40

If a search fails to find a projector, the most likely causes are as follows. Proceed as appropriate, depending on the cause of the failure.

- For both Windows and Macintosh
- If there is no wireless LAN signal or if the signal is weak, check whether there is anything that could be interfering with the signal.
- When the supplied or optional Wireless LAN unit is installed in the projector, and Macintosh is connected to a Wireless LAN Check whether AirPort is set to On. Or, check whether an appropriate access point has been selected.

38

TOP

In the following explanations, unless otherwise noted, Windows screen shots are used.

You see the similar screens even when using Macintosh.

Procedure

Click "Manual search" on the EasyMP Network Projection Select a projector screen. Click "Manual search".

Status		Projector name	IP address	
) Standby	EMP02FAC1	192.	168.11.1
) Standby	EMP02FAC2	192.	168.11.2
) Standby	EMP02FAC3	192:	168.11.3
_	terrupt connei	l	Save in the profile	Clear list



Enter the IP address or the Projector name for the projector you want to connect to, and click "OK".

Manual search	\mathbf{X}
Enter the projector IP address or name.	
OK Cancel	

The search results are displayed on the EasyMP Network Projection Select a projector screen.

Provided the target projector has been identified, select that projector, and then click **Connect** to establish a connection. When you will always be using that projector, save the search as a Profile, so that you do not have to specify the relevant details every time you perform a search. \bigcirc p.40



When using **Manual search** in Quick Connection Mode, you can specify the SSID. When there are a lot of projectors you can narrow the search field by using SSID.

TOP

40

You can save a search for a frequently used projector as a Profile. A Profile is a file containing all of the information pertaining to a given projector, such as the Projector name, its IP address, and SSID. By specifying the profile each time you perform a search, there is no need to enter the IP Address or Projector name. For example, by creating a group of Profile for each place where a projector is setup and managing them with folders, the target projector can be found quickly.



This section explains how to create and edit a Profile.

Making a Profile

Profile is made by saving search results.

For details on how to edit a previously saved Profile, see the following section. ${\color{black}{\textcircled{\black}}} p.42$

Procedure

When the projector is displayed on the EasyMP Network Projection Select a projector screen, click "Save in the profile".

Projector name IP address ndby EMP02FAC1 192168.11.1 ndby EMP02FAC2 192168.11.2 ndby EMP02FAC3 192168.11.3 Save in the profile Clear list
EMP02FAC2 192168.11.2 ndby EMP02FAC3 192168.11.3
ndby EMP02FAC3 192.168.11.3
Save in the profile Clear list
Save in the profile Clear list
Save in the profile D Clear list
connection

The Save in the profile screen is displayed.

Enter a Profile name and then click "Add".

Save in the pr	ofile		×
Enter the Profile	Name.		
Profile name	Untitled		
	Add	Cancel	

Projector information is registered in the Profile.

If you have previously saved a Profile, you are prompted to confirm whether it can be overwritten. To save a Profile with a different name, select **Save as**. If you have created a folder for a



Profile, the following screens are displayed. After entering the Profile name and selecting the **Save in** destination, click **Add**.

For Windows

Inter the profile name and specify where to save the profile. Profile name Profile Profile Profile Add Cancel
Save in
building A building B
Add Cancel
Add Cancel
Add Cancel
Save in the profile
Enter the profile name and specify where to save the profile.
Profile name Untitled
Save i 🗸 Profile
Building A Building B
For details on how to create a folder for a Profile, see following section. \bigcirc p.42

Searching by Specifying a Profile

You can search by specifying the Profile you created.

Procedure



Click "Profile" on the EasyMP Network Projection projector selection screen.

If no Profile is registered, you cannot select Profile.

🚰 EasyMP Network	Projection Ver.X.	🗙 – Advanced Connection – 🛛 🔳 🗖 🗙		
Automatic search Annual search Profile -				
Select a projector and connect it.				
Status	Projector name	IP address		
🔲 💷 Standby	EMP02FAC1	192.168.11.1		
🔲 💷 Standby	EMP02FAC2	192.168.11.2		
🔲 💽 Standby	EMP02FAC3	192.168.11.3		
Disable interrupt conne	ction	Save in the profile Clear list		
Use multi-display Set options				
Troubleshooting				

2

From the menu that is displayed, select the projector you want to connect to.

🚰 EasyMP Network P	rojection Ver.X.	🗙 – Advanc	ed Connection -	
Automatic search	Manual search	Profile	•	
Select a projector and conn	nect it.	Building A		
Status	Projector name	Building B	Building B 1st floor	
🗹 📷 Standby	EMP02FAC1	192.168.11.1	Building B 2nd floor	1

The search results are displayed on the EasyMP Network Projection Select a projector screen.

Provided the target projector has been identified, select that projector, and then click **Connect** to establish a connection.

Performing a Search with a Profile

Managing a Profile

You can change the name and the hierarchical structure of the Profile.

Procedure

Click "Set options" on the EasyMP Network Projection main screen.

The Set options screen is displayed.



Click "Edit profile".



The Edit profile screen is displayed.



Network Projection main

Edit profile Profile

Profile

🖃 📄 building B

building B 1st floor



Information on selected profile

Projector name

EMP02FAC1

EMP02FAC2

EMP02FAC3

IP address

192.168.4.251

192.168.4.252

192.168.4.253

Profile	
ltem	Function
Profile	You can display the registered Profile. You can manage it by creating a folder.You can change the order of the Profile or the folder by dragging & dropping.
Сору	You can copy the Profile. The copied Profile is saved in the same folder as the original with the same name.
Delete	You can delete the Profile and the folder.

88

Profile	
ltem	Function
Rename	You can display the Rename dialog box and rename the folder or the Profile.You can enter up to 32 characters in the Rename dialog box.
Create folder	You can create a new folder.
Export	You can Export a Profile, as well as Import and use a Profile.
Import	Used when you want to read and use an exported Profile.

Information on sele	ected profile
ltem	Function
Projector name, IP address	You can display the projector information registered in the Profile.
Delete	You can delete the information for the selected projector. When all projector information is deleted, the profile is also deleted.

(4) Click "OK".

Saves your edits and closes the Edit profile screen.



Setting the EasyMP Network Projection Operation

You can make setting options such as the processing method when EasyMP Network Projection starts.

Using Set options



You can make setting options such as the processing method when EasyMP Network Projection starts.

Call Set options from the EasyMP Network Projection main screen.

Procedure

Click "Set options" on the EasyMP Network Projection main screen.

🚰 EasyMP Network P	rojection Ver.X.	🛠 - Advanced Connection - 💦 🗖 🔀		
Automatic search	Manual search	Profile •		
Select a projector and connect it.				
Status	Projector name	IP address		
🔲 🚺 Standby	EMP02FAC1	192.168.11.1		
🔲 证 💿 Standby	EMP02FAC2	192.168.11.2		
🗌 💽 Standby	EMP02FAC3	192.168.11.3		
Disable interrupt connec	ction	Save in the profile Clear list		
Use multi-display		Set options		
Troubleshooting				

The Set options screen is displayed.

Set each of the items.

Confirm the details of the set items in the next step. When you have made all the necessary settings, click **OK** to close the Set options screen.

Setting Each Item

Set each item from the General settings tab, the Adjust performance tab, and the Audio Output tab.

General settings tab

Set options
General settings Adjust performance Audio Output
Use full-screen video transfer Encrypt communications Display Connection Mode Selection window on startup Search method on startup Automatic search on startup Specify search method after startup Search with the last network configuration Edit profile Switch LAN
Restore Defaults OK Cancel

Use full-screen video transfer	Windows only (excluding Windows Vista) Select this check box when you want to display Windows Media Player in full screen. However, clear this check box if the movie does not play back smoothly.
Encrypt communications	Select to Encrypt and transmit data. Even if data is intercepted, it cannot be decrypted. When using Quick Connection Mode, make sure you always select this check box.
Display Connection Mode Selection window on startup	Set whether or not the Quick Connection Mode/ Advanced Connection Mode screen is displayed when EasyMP Network Projection starts. Clear this check box once you have settled on a regular startup method.

Using Set options

Search method on startup	Select from the following projector search methodsexecuted when EasyMP Network Projection is started.Automatic search on startupSpecify search method after startupSearch with the last network configuration	
Edit profile	The Edit profile dialog box is displayed. The P.42	
Switch LAN	Windows onlyThe Switch Network Adapter dialog box is displayed.This is used when it is necessary to switch the network adapter to be used for a search when a computer has multiple adapters.By default, all of the network adapters are used to perform a search. When a Wired LAN is always used as the connection method, select a Wired LAN adapter.	
Restore Defaults	You can reset all adjustment values on the General settings tab to their default settings, except for Edit profile and Switch LAN.	

Adjust performance tab

Set options			
General settings Adjust performance	Audio Output		
Fast		Normal	Fine
1 I I I I I I I I I I I I I I I I I I I	1		
Transfer layered window			
			Version
Restore Defa	ults	ОК	Cancel

Performance adjustment slider	The performance can be set to Fast , Normal , and Fine . Set to Fast when movie projections are interrupted.
Transfer layered window	Windows only (excluding Windows Vista) Set whether or not to transfer a layered window. The layered window is in use when contents such as messages displayed on the computer are not projected by the projector. Select this check box to project contents such as messages that use the layered window. Clear this check box if you do not want the mouse pointer to flicker on the screen.
Restore Defaults	You can reset all adjustment values for the Adjust performance tab functions to their default settings.

Using Set options





Audio Output tab

Set options			
General settings A	djust performance	Audio Output	
V Output audio I	from the projector		
	Restore Defa	ults	OK Cancel

Output audio from the projector	Set whether or not to transfer the computer's audio to the projector and output. Clear to output audio from the computer. However, when projecting a movie with audio in Movie Sending Mode, audio is output from the projector regardless of this item's setting.
Restore Defaults	Click to set the audio to output from the projector.



Using a Computer to Set Up, Monitor and Control Projectors

This chapter explains how to use a computer that is connected to the network to change projector settings and to control the projector.

You can set up and control the projector from a computer by using the Web browser of a computer that is connected to the projector via a network. Setup and control operations can be performed remotely if this function is used. In addition, since you can use the computer's keyboard, entering characters required for the setup is easier. Use Microsoft Internet Explorer 6.0 or later as the Web browser.If using a Macintosh, you can also use Safari. If, however, you are using Safari under Mac OS X 10.2.8, some of the Web control radio buttons may not display properly.



Setup and control with a Web browser are possible if **Network On** is set from the **Extended** menu of the projector's Configuration Menu, even if the projector is in **Standby Mode** (when the power is off).

Displaying Web Control

Use the following procedure to display Web Control.



If your Web browser is set up to connect via a proxy server, Web Control cannot be displayed. To use Web Control, you need to make network connection settings with a device other than a proxy server.

Entering the IP address of the projector

Web Control can be opened by specifying the IP address of the projector as follows when using Advanced Connection Mode.

Procedure

(1)

Start the Web browser on the computer.

Enter the IP address of the projector in the address input box of the Web browser, and press the [Enter] key on the computer's keyboard.

Web Control is displayed.

When Web Control Password is set in the Network menu from the projector's Configuration Menu, enter the Password. Enter EPSONWEB as the User name. Enter the character set for the Web Control Password as the password.

Projector Setup

You can set items that are usually set in the projector's Configuration Menu. The contents set are reflected in the Configuration Menu. There are also items that can only be set in the Web browser.

Items in the Configuration menu that cannot be set by the web browser

All items in the Configuration Menu can be set with the exception of the following items.

- Settings Menu Pointer Shape
- Settings Menu Test Pattern
- Settings Menu User Button
- Extended Menu registering User's Logo
- Extended Menu Language
- Extended Menu Operation High Altitude Mode
- Extended Menu Operation Lens Cover Timer
- Reset Menu Reset All, and Reset Lamp Hours

The items available on each menu are the same as the Configuration Menu of the projector.

Changing Settings Using a Web Browser (Web Control)

Items that can only be set in the Web browser

The following items can only be set in a Web browser.

- SNMP Community Name
- Monitor Password



50

By setting the Mail Notification function from the projector's Configuration Menu, notification messages will be sent to the preset email addresses when a problem or warning occurs with a projector. This will enable the operator to be notified of problems with projectors even at locations away from the projectors.

- ÷ ا
- Up to a maximum of three notification destinations (Addresses) can be recorded, and notification messages can be sent to all three destinations at once.
- If a projector develops a critical problem and suddenly stops working, it may not be able to send a message notifying an operator of the problem.
- Monitoring is possible if Network On is set from the Extended menu of the projector's Configuration Menu, even if the projector is in Standby Mode (when the power is off).

51

By setting SNMP from the projector's Configuration Menu, notification messages are sent to preset e-mail addresses when a problem or warning occurs with a projector. This is useful when controlling projectors collectively at a point distant from them.

کر:

• SNMP should be managed by a network administrator or someone who is familiar with the network.

- To use the SNMP function to monitor the projector, you need to install the SNMP manager program on your computer.
- The managing function using SNMP cannot be used via Wireless LAN in Quick Connection Mode.
- Up to two destination IP addresses can be saved.





Presentations Using PC Free

This chapter explains how to directly project image and movie files stored on USB devices, and scenarios created with EasyMP Slide Converter, using PC Free.

You can use PC Free to directly project files stored in USB storage devices and digital cameras that are connected to the projector.



USB storage devices that incorporate security functions sometimes cannot be used.

Specifications	for	Files	that	can	be	Projected
Using PC Free						

Туре	File Type (Ex- tension)	Notes
Scenario file	.fse .sit [*]	These are scenario files created using EasyMP Slide Converter. • p.65
Image	.jpg	 The following cannot be projected. Images with a resolution greater than 8192 x 8192 Images with a file size greater than 12 MB Files with the extension ".jpeg" CMYK color mode formats Progressive formats Normally, the image may not be projected clearly if compression is set too high.
	.bmp	Cannot project images with a resolution greater than 1024 x 768.
	.gif	 Cannot project images with a resolution greater than 1024 x 768. Cannot project animated GIFs.
	.png	Cannot project images with a resolution greater than 1024 x 768.

TypeFile Type (Ex-
tension)NotesDPOF.mrkFor DPOF version 1.10, only files named
AUTPLAYx.mrk (where x is a number between 0 to
9) can be projected.

* You can also project scenarios (SIT files) created using the EMP SlideMaker/EMP SlideMaker2 supplied for other projectors.

File Type (Exten- sion)	Movie Codec	Audio Codec	Recording Quality
.mpg*	MPEG-2	MPEG-1 Layer1/2 MPEG contents with no sound can be played back. Linear PCM and AC-3 audio cannot be played back.	Highest frame rate: 30 fps Maximum resolution: 720 x 480 (NTSC) 720 x 576 (PAL)
.mp4*	MPEG-4 ASP MPEG-4 AVC	MPEG-4 AAC-LC	
.wmv .asf	WMV8 WMV9	WMA	

* Files with the extension .mpeg cannot be projected.

Supported movie files

TOP

- Files to which DRM (Digital Rights Management) is applied cannot be projected.
- If you use a USB storage device with a slow access speed when playing back movies (when transmitting at higher bit rates), the movie files may not play back correctly or the sound may skip or not be output.
- When using a USB hard disk, we recommend using an AC adapter power supply.
- The projector does not support media formatted on some file systems. If you have trouble when projecting, use media formatted under Windows.
- Format the media using the FAT16/32 file system.

PC Free Examples

-Q

Projecting images and movies stored on USB storage and so on



Image and movie files can be played back using either of the following two methods. By using PC Free, projected movies look much smoother

than those projected by playing back using other applications on a computer.

Example 1: Prepare multiple images and project them continuously (Slideshow) (**p**.63)

Example 2: Select image files and movie files one at a time and project ${\color{black} \bullet } p.62$

Projecting a PowerPoint Slide Show without connecting to a computer

You can use EasyMP Slide Converter to convert your PowerPoint file into scenario format. By storing this scenario file on a USB storage device, you can project a PowerPoint Slide Show without connecting a computer.



The playback method for the file to be projected can be set as follows during conversion.

Example 1: Convert a PowerPoint file into a scenario and project

- ☞ "Converting PowerPoint Files to Scenarios" p.67
- ☞ "Projecting Scenarios" p.59

Example 2: Set scenario to automatic playback (AutoRun)

Converting PowerPoint Files to Scenarios" p.67

PC Free Basic Operations

PC Free lets you play back and project scenarios, images, and movie files stored in USB storage devices, and image files in digital cameras. This section explains the basic operations for PC Free.

Although the following steps are explained based on the Remote Control, you can perform the same operations form the projector's Control panel.

Starting and Closing PC Free

Starting PC Free

Procedure

Switch the projected image to USB1.

☞ User's Guide "Switching to the Target Image Using the Remote Control"

Connect the USB storage device or digital camera to the projector.

☞ User's Guide "Connecting and Removing USB Devices (EB-1925W/1920W/1915/1910/1830 only)"





JPEG files and MPEG files are displayed as thumbnails (file contents are displayed as small images). Scenarios (FSE files and SIT files) are displayed as thumbnails as the first image in the slide. Other files or folders are displayed as icons as shown in the following table.

lcon	File	lcon	File
FSE	FSE files*	DPOF	Format for digital camera
SIT	SIT files [*]	MPEG	MPEG files
JPEG	JPEG files [*]	WMV	WMV files
BMP	BMP files	PFX	PFX files (client certificate)

56

<u>ک</u>





- When it cannot be displayed as a thumbnail, it is displayed as an icon.
 - When AutoRun is set for a scenario, it is automatically played back with the highest priority over other input sources. If you want to stop it from playing back, press the [Esc] button on the remote control. p.67
 - You can also connect a memory card to the projector by loading it in a USB card reader. However, some card readers may not be compatible.
 - When the following screen (Select drive screen) is displayed, press the [] [] [] [] [] buttons to select the drive you want to use, and then press the [Enter] button.



- To display the Select drive screen, position the cursor on Select drive in the top half of the file list screen, and then press the [Enter] button.
- The projector can recognize up to eight drives at a time.

Closing PC Free

Procedure

To close PC Free, disconnect the USB device from the USB1 port on the projector. For digital cameras, hard disks, and so on, turn off the power to the device and then disconnect.

PC Free Basic Operations

The following describes the procedures for playing images, movies, and scenarios, using PC Free, and projection operations.

Procedure



Use the [] [] [] [] [] [] buttons to position the cursor on the file or folder you want to access.



Cursor

PC Free Basic Operations



ک

If all files and folders cannot be displayed at the same time in the current window, press the [Page] (Down) button or position the cursor on **Next page** at the bottom of the screen and press the [Enter] button.

To return to the previous screen, press the [Page] (Up) button or position the cursor on **Previous page** at the top of the screen and press the [Enter] button.



Press [Enter].

The selected image is displayed.

When a folder is selected, the files in the selected folder are displayed. Select **Back to Top** and press the [Enter] button to return to the screen displayed before the folder was opened.

Rotating the Image

You can rotate JPEG images in 90° increments when playing them with PC Free. The rotating function is also available during the Slideshow.

Rotate JPEG images in the following way.

Procedure



While projecting a JPEG image, press the [\frown] or the [\frown] button.











Projecting Scenarios

This section describes the method for playing scenarios stored in a USB storage device, and the operations during scenario playback.

Although the following steps are explained based on the Remote Control, you can perform the same operations form the projector's Control panel.

Creating and Editing a Scenario

Create the scenario beforehand by using EasyMP Slide Converter, and then transfer it to the USB storage device. \bigcirc p.65

Basic SIT file editing

For SIT files converted via EasyMP Slide Converter basic conversion \bigcirc p.67, it is possible to change the order in which images are projected, and set whether or not to display individual images.

Basic editing cannot be performed for FSE files.

Procedure

-Ö

- Press the [<>][<>][()][()] buttons to position the cursor over the SIT file you want to edit and press the [Esc] button.
- Select " Edit Scenario" from the menu displayed, then press the [Enter] button.



(3) Po [E:

Position the cursor on the desired slide, and then press the [Esc] button.

The sub menu is displayed.

Select **Move Files** to change the order of the slides, and **Show**/ **Hide** to show or hide files, then press the [Enter] button. Go to step 4 when you select Move Files.

Go to step 4 when you select move thes.

Go to step 5 when you select Show/Hide.



Move the cursor to the desired position, and then press the [Enter] button.



- The Slide to move
- The cursor at the target destination

When you have finished editing, position the cursor over " Edit Complete" at the top of the screen, and then press the [Enter] button.

The edited content can only be accessed while the USB storage device is connected to the projector.

Playing a Scenario

Procedure

Start PC Free. P.56

The file list screen is displayed.





÷ ∭َ

Press the [Enter] button.

Starts playback.

• You can rotate JPEG format images in the scenario while they are being projected. p.58

• The movie files that are included in scenarios can be fast-forwarded, rewound and paused during playback. (p.62

Operating During a Presentation

The following operations are possible using the remote control while playing a scenario.

Screen Switching	 For FSE files [Page] (Down)/ : Next Slide [Page] (Up)/ : Previous Slide [Enter]/(*): Next Slide or object (*): Previous Slide or object For SIT files [Enter]/[Page] (Down)/(*): Next Slide or object [Page] (Up)/(*): Previous Slide or object
Stopping Playing	The message " Do you want to quit playing the scenario? " is displayed when you press the [Esc] button. Close by selecting Exit and pressing the [Enter] button. Continue playback by selecting ESC and pressing the [Enter] button.

The following projector functions can be used when projecting a scenario or image file with PC Free.

- Freeze 🖝 User's Guide "Freezing the Image (Freeze)"
- A/V Mute 🖝 User's Guide "Hiding the Image and Sound Temporarily (A/V Mute)"



• E-Zoom 🖝 User's Guide "Enlarging Part of the Image (E-Zoom)"

Projecting Image and Movie Files

Image and movie files stored on a USB storage device and image files on a digital camera can be projected using PC Free by either of the following two methods.

- Projecting Selected Image and Movie Files This is a function for projecting single files.
- Projecting all image and movie files in a folder in sequence (Slideshow)

This is a function for projecting the file contents of a folder in order, one file at a time.

Attention

The USB storage device is accessed frequently when playing back movie files. Do not disconnect the USB storage device at this time.PC Free may not operate correctly.

Although the following steps are explained based on the Remote Control, you can perform the same operations form the projector's Control panel.

Projecting Movies and Images

Procedure

Start PC Free. p.56

The file list screen is displayed.

Use the [] [] [] [] [] [] buttons to position the cursor on the image file or movie file to be projected.



Image file 0

Press [Enter].

The image or movie starts to play back.



The following operation returns you to the file list.

- While projecting still images: Press the [Esc] button.
- While projecting movies: Press the [Esc] button. On the screen that is displayed, select Exit, and then press the [Enter] button.



- -Č
- JPEG format images can be rotated during projection. T. p.58
- You can make the following operations using the remote control while playing movie files.
 Fast-forward: Press the [①] button
 - Rewind: Press the [] button
 - Freeze (Pause): Press the [____] button
 - To return to normal playback, press the [Enter] button. Audio is not output while fast-forwarding, rewinding, or pausing are in progress.

Projecting all Image and Movie Files in a Folder in Sequence (Slideshow)

You can project the image and movie files in a folder in sequence, one at a time. This function is called Slideshow. Perform the Slideshow by the following procedure.



You can set display conditions, such as projecting repeatedly and adding display effects while files are being switched. To change movie and image files automatically when you run Slideshow, set the Screen switching time in the PC Free Option menu to anything other than **No**. The default setting is **No.** p.64

Procedure



Start PC Free. P.56

The file list screen is displayed.

Use the [][]][]][]][]] buttons to position the cursor over the folder for the Slideshow that you want to run and press [Enter].

Select Slideshow from the file list screen, and then press the [Enter] button.

The Slideshow starts and the image and movie files in the folder are automatically projected in sequence, one at a time.

When the last file is projected, the file list screen is automatically displayed again. If you set **Continuous Play** to **On** from the Option screen, projection starts again from the beginning when it reaches the end. \bigcirc p.64

Just as with a scenario, you can proceed to the next screen, return to the previous screen, or stop playback during projection of a Slideshow. Toperating During a Presentation p.60



If the Screen switching time setting on the Option screen is set to **No**, files do not change automatically when you start a Slideshow. Press the [Enter] button or the [Page] (Down) button on the Remote Control to continue to the next file.



You can set the file display order and the Slideshow operations on the Option screen.

Procedure



Position the cursor on "Option" at the bottom of the file list screen, and then press the [Enter] button.

(2)

When the Option screen is displayed, set each of the items.

Enable settings by positioning the cursor on the target item and pressing the [Enter] button.

Details of the items are given below.



Display order	You can set the order of the files to be displayed. You can select sorting of the files into either Name order or Date order .
Continuous Play	You can determine whether to repeat the Slideshow.
Screen switch- ing time	You can set the time for a single file to be displayed when playing a Slideshow. You can set a time between No (0) and 60 Seconds. When you set No , auto play is disabled.

Effect You can set the screen effects when changing slides.



cursor over "OK" and press [Enter].

The settings are applied.

If you do not want to apply the settings, position the cursor on **Cancel** and press the [Enter] button.



Preparing a Scenario (Using EasyMP Slide Converter)

This chapter explains how to convert a PowerPoint file to a scenario, and how to transfer to a USB storage device.

Scenario Summary





Transfer the created scenarios to a USB storage device connected to the computer. Connect the USB storage device on which the scenarios are stored to the projector and start projection using PC Free. They are scenario" p.60



EasyMP Slide Converter should be installed on the computer. For details on installing EasyMP Slide Converter see 🖝 p.12



You can convert PowerPoint files and play back scenarios directly from the projector without needing to connect a computer.

Convertible PowerPoint Files

In EasyMP Slide Converter, files created with Microsoft PowerPoint 2002/2003/2007 (extensions .ppt/.pps/.pptx) can be converted into scenarios.

Scenario Conversion Procedure

Scenarios are converted using the following procedure.

- 1. Start EasyMP Slide Converter, and select the PowerPoint file.
- 2. On the Set screen, make settings such as Save to, Conversion Mode, and Projector Resolution, and then convert to a scenario.
- 3. Preview the converted scenario (FSE file).
- 4. Copy the scenario to the USB storage device connected to the computer.
- 5. Set the scenario to AutoRun.

Explanation of the Main Screen

Start EasyMP Slide Converter to display the Main screen. The functions for each button are described in the following table.



	Button Name	Explanation
0	Convert	Click to display the File Selection screen. Select a PowerPoint file and convert it to a scenario. Converting to a Scenario" procedure 3
2	Preview	Click to display the File Selection screen. Select and preview the converted scenario (FSE file).
3	Copy to Memory	Click to display the File Selection screen. Select the file you want to copy to USB storage and then copy. Converting to a Scenario" procedure 8
4	Edit AutoRun	Click to display the Edit AutoRun screen. Edit AutoRun. Converting to a Scenario" procedure 9
5	Set	Click to display the Set screen. Make file settings such as Save to, Resolution, and Conversion Mode. Converting to a Scenario" procedure 4



When the After converting a file, copy it to memory. check box is selected in the Set screen, messages are displayed to guide you through making settings for each item. By following the instructions in the displayed message you can make settings for each item. When this check box is cleared, make each setting from the Main screen.

Converting to a Scenario

This section explains how to convert a scenario step-by-step.

Procedure

Select "Start" - "Programs" (or "All Programs") - "EPSON Projector" - "EasyMP Slide Converter".

The EasyMP Slide Converter Main screen is displayed.

Connect the USB storage device to the computer to save the scenario.

3) Click () on the Main screen. Select the PowerPoint file to be converted into a scenario, and then click "Select".

The Set screen is displayed. Enter each of the items by referring to the following table, and then click "Next".

et 🛛 🔀
File Product_001.ppt
Save to Desktop
Same location as file
O Specify Directories
Conversion Mode
Play a slideshow and convert files
Convert files without playing a slideshow
O Perform simplified conversion
Play a slideshow and convert files. During conversion, operations with other applications cannot be performed.
Projector Resolution
• XGA (1024 x 768 dots)
O WXGA (1280 x 800 dots)
After converting a file, copy it to memory.
Advanced
Image
High Image Quality Normal
Animation Transition Time
If the animation cannot be converted correctly, change the following setting to increase the reproducibility. However, increasing the reproducibility will increase the conversion time.
Short Normal Long
· · · · · · · · · · · · · · · · · · ·
\sim
Advanced << Restore Defaults Version information Next Cancel

File	The file name for the selected PowerPoint is displayed.
Save to	Select where to save the scenario.
Conversion Mode	 Select the conversion method for the PowerPoint file. Play a slideshow and convert files The Slideshow is displayed during conversion allowing you to check the Slideshow as it is converted. Cannot operate other applications during conversion. The file is saved in FSE format.
	• Convert files without playing a slideshow A Slideshow is not displayed during conversion. The effects for the set slides are not converted. The file is saved in FSE format.
	• Perform simplified conversion Convert to a JPEG file. None of the set animations are converted. The file is saved in SIT format.



69

Projector Resolu- tion	Select the Resolution for the projector that will project the scenario. Scenarios for which WXGA (1280 x 800 dots) has been set cannot be played back on XGA type projectors.
After converting a file, copy it to memory.	Select to follow the conversion procedure step-by-step. When selected, the Set screen is displayed each time a file is converted.
Image	Set the image quality for the converted file. When Normal is set, the file size is smaller compared to High Image Quality, but the image quality is degraded. High Image Quality is recommended. When Perform simplified conversion is selected in Conversion Mode, image quality cannot be set.
Animation Tran- sition Time	Set the animation reproducibility (transition time) for the converted file. When Perform simplified conversion is selected in Conversion Mode, a transition time cannot be set.
Advanced	Switch between Show/Hide for Advanced.
Restore Defaults	Changed settings are returned to their default values. Click OK to save the settings.
Version informa- tion	Display version information for the application.

- You can modify setting details by clicking the **Set** button on the EasyMP Slide Converter Main screen.
- In Windows 2000, you cannot select **Convert files without** playing a slideshow from Conversion Mode.

-Ŵ

- If the resolution for the computer being used does not have 1280 x 800 or 1280 x 768 settings, and **Play a slideshow and convert files** is selected, you cannot select WXGA for the Projector Resolution.
- Cannot convert audio and movies in PowerPoint files or animations such as PowerPoint Game.
- Effects set for the first slide cannot be converted regardless of the Conversion Mode.
- When **Convert files without playing a slideshow** is selected, screen switching effects cannot be converted.
- Animations for which timer or repeat are set may not be converted normally. If you cannot convert the Animation correctly, set a longer standby time to increase the reproducibility.
- Cannot convert when the slide display settings in the PowerPoint file are set to Slide or when Custom Slide Show is set.

When the confirmation screen is displayed, check the content and then click "Convert".



- ---
- For Play a slideshow and convert files, it is automatically modified to use the screen's resolution depending on the projector's resolution (XGA or WXGA). After conversion, it returns to the previous screen resolution.
- If PowerPoint is running. the conversion process cannot be performed. Close PowerPoint before starting conversion. Also, do not start PowerPoint during conversion.
- During conversion, do not modify the display setup such as changing the resolution or connecting an external monitor. If the display setup is changed, conversion is canceled.
- If After converting a file, copy it to memory is not selected on the Set screen, the screens from procedure 6 are not displayed. When the main screen is displayed, preview a scenario or copy to memory by using the appropriate buttons on the main screen.

6

When the Preview confirmation screen is displayed after conversion is complete, click "Yes". If you do not want to view the Preview, click "No" and go to procedure 7.

The Preview screen is displayed. The following table shows the functions of each button.



duct_001.fse Preview

▶ Play	Starts preview. Also, this restarts stopped or paused scenarios. If Animations in PowerPoint files are not played back automatically, Animations can be played back one after another by pressing the Play button.
Pause	Pauses the Preview. When the Pause button is pressed while Animations are being played back, the Animation is paused.
Stop	Stops playback and returns to the first slide.
H Previous Slide	Returns to the previous slide.
▶ Next Slide	Advances to the next slide.

When the preview has finished, close the Preview screen.



Jpeg (SIT) files cannot be previewed with the Preview function. When **Perform simplified conversion** is selected from Conversion Mode, the Copy confirmation screen is displayed but the Preview confirmation screen is not displayed.



When the Copy confirmation screen is displayed, click "Yes".



The Select Copy Location screen is displayed. Select the drive where the USB storage is connected and the copy location, and then click "OK".

To set AutoRun, select Play automatically. (AutoRun setting).

Select Copy Location 🛛 🔀		
Product 001.fse Select the location	n to copy the file.	
Copy to	E:¥	Browse
✓ Play automatic	ally. (AutoRun setting)	OK Cancel

The scenario is transferred to the selected destination.

When transfer is complete, one of the following screens is displayed.

When there is no AutoRun file in the USB storage device:

The Continuous Play confirmation screen is displayed. When you want to create an AutoRun file and set the Continuous Play setting for the AutoRun file to On, click **Yes**.

When you want to create an AutoRun file and set the Continuous Play setting for the AutoRun file to Off, click No.

EasyMP Slide Converter	
Do you want to play the copied	f file continuouslu?
Do you want to play the copiet	The continuously:
	Yes No

When there is an AutoRun file in the USB storage device:

Set AutoRun with reference to the following table, and then click OK.

Edit AutoRun		×
	Drive 🗢 USBMemory (G:) 🔽 Continuous Play	
File List	AutoBun File List	
Product_001.fse Product_002.fse	/Product_001.fse	
	OK Cancel	

Drive	Select the drive to edit the AutoRun file.
Continuous Play	To start projecting from the first scenario again once projection of all scenarios in the "AutoRun File List" is complete, select this check box.
File List	A list of scenarios for which AutoRun is not set is displayed. The scenario file is displayed in the format Folder name/File name.
AutoRun File List	A list of scenarios for which AutoRun is set is displayed in playback order. Click the 🔹 🔹 buttons to change the order.
+ +	The scenario is registered and deleted in the AutoRun file.



If there are two or more files set for AutoRun, they are played back in order from the top of the AutoRun File List.



Remove the USB storage device from the computer.

See the computer's user's guide for the removal method.



After finishing transferring your scenario, connect the USB storage device to the projector and start projection using PC Free. **p.56**



When the resolution of the projector that is projecting the scenario is XGA type, scenarios for which WXGA (1280 x 800 dots) is set cannot be played back. Project after converting the PowerPoint file to an XGA (1024 x 768 dots) scenario file.

Converting Directly from a PowerPoint File to a Scenario

This section explains how to convert directly from a PowerPoint file to a scenario.



This is useful when you want to convert without modifying any settings. Because the settings from the Set screen are reflected during conversion, check the settings before hand when After converting a file, copy it to memory is not selected.

Procedure



Drag & drop the PowerPoint file icon to the EasyMP Slide Converter program icon on the desktop. Or, right click the PowerPoint file and select " Convert to FSE".

Note that, in this case, it is not possible to select multiple PowerPoint files and convert them. Select only one file for conversion.



EasyMP Slide Converter starts.

EasyMP Slide Converter		
File to Convert	Product_001.ppt	
Save to	Desktop	
Conversion Mode	Play a slideshow and convert files	
Projector Resolution	XGA (1024 x 768 dots)	
Image	High Image Quality	
Animation Transition Time	Normal	
The display resolution will be changed for file conversion.		
Do not change the screen settings during conversion.		
If PowerPoint® is running, close it before converting a file.		
Convert using these settings?		
	Convert Cancel	

Converting the file to a scenario starts. When **Play a slideshow** and convert files is selected from Conversion Mode, the Slideshow is displayed.

When "After converting a file, copy it to memory." is not selected, the main screen is displayed when conversion is complete.

When "After converting a file, copy it to memory." is selected, go to procedure 6 **(Converting to a Scenario**".


Sa EasyM	P Slide Co	nverter V	er. X.XX (
		→	×.	P

Then make setting such as scenario preview, copy to memory, and AutoRun. TExplanation of the Main Screen" p.67



Appendix

When projecting computer images while running EasyMP Network Projection, the following restrictions apply. Confirm these points.

Supported Resolutions

The following computer screen resolutions can be projected. You cannot connect to a computer with a resolution greater than \underline{UXGA}^{\flat} .

- <u>VGA</u> (640x480)
- <u>SVGA</u> (800x600)*
- <u>XGA</u> (1024x768)*
- <u>SXGA</u> (1280x960)
- SXGA (1280x1024)*
- SXGA+ (1400x1050)*
- WXGA (1280x768)
- WXGA (1280x800)
- WXGA+ (1440x900)
- UXGA (1600x1200)
- * Supported resolutions when multi-screen display function is on.

If a computer with a special screen size is used where the ratio of height and width is not represented, a screen resolution closest to the width is selected from the list of 10 above.

In this case, in wide screen the horizontal margins are projected, in narrow screen the empty vertical margins are black.

Display Color

The number of colors for computer screens that can be projected.

Windows	Macintosh
16-bit color	About 32,000 colors (16-bit)
32-bit color	About 16.7 million colors (32-bit)

The operational guarantee for multi-screen display is 16-bit and 32-bit color.

Number of Connections

You can connect up to four projectors to one computer and project simultaneously.

You cannot connect multiple computers to one projector simultaneously.

Others

- If the transmission speed of the Wireless LAN is low, the network might be cut off unexpectedly.
- Audio can only be transferred to one projector. Audio cannot be transferred when connected to multiple projectors.
- When videos are played back, they do not play back as smoothly as when displayed on the computer.
- Applications that use part of DirectX functions may not be displayed correctly.(Windows only)
- Cannot project full screen MS-DOS prompts.(Windows only)
- There are times when the image on the computer screen and the image projected by the projector may not match exactly.

When Using Windows Vista

Note the following points when using EasyMP Network Projection with a computer running Windows Vista.

Limitations when projecting from Windows Photo Gallery

Note the following two limitations when launching Windows Photo Gallery when EasyMP Network Projection is running.

TOP

• Slide Show is played back in simple mode when projecting from Windows Photo Gallery.

Because the toolbar is not displayed, you cannot make changes while playing a Theme (effects), regardless of the Windows Experience Index rating.

Once simple mode has started, you cannot change modes while Windows Photo Gallery is running even if you close EasyMP Network Projection. Restart Windows Photo Gallery.

• You cannot play movies.

Limitations in Windows Aero

Note the following two limitations when the window design for your computer is Windows Aero.

• The layered window is projected regardless of Transfer layered window from Set options in EasyMP Network Projection. For example, when Transfer layered window for the EasyMP Network Projection toolbar is disabled, it is not projected even if it is displayed on the computer screen, however the toolbar is projected. • A few minutes after you connect a computer to the projector over a network with EasyMP Network Projection, the following message is displayed.

It is recommended that you select **Keep the current color scheme**, and don't show this message again. This selection is enabled until the computer is restarted.



Making Effective Use of When Security is set to EAP-TLS from the projector's Network menu, Your Projector you need to register the client certificate and the CA certificate in the Save the client certificate and the CA certificate are in a USB storage 13

 \overline{Q}

projector for authentication.

• The client certificate and the CA certificate need the extensions PFX (.pfx) and CER (.cer) respectively.

• Only one set of client certificate and CA certificate can be registered in the projector. If another digital certificate is registered, it overwrites the previous certificate.

Registering a Client Certificate

device, and register to the projector with PC Free.

Procedure

Connect the USB storage device on which the Digital certificate is stored to the projector and start PC Free. **p.56**

The file list screen is displayed.

Press the [] [] [] [] [] [] buttons on the remote control to position the cursor over the client certificate (PFX file) icon and press the [Esc] button.



Select "Digital certificate" from the menu displayed, then press the [Enter] button. The following window is displayed.



Enter the password using the soft keyboard. (You can enter up to 32 alphanumeric characters)
User's Guide "Soft keyboard operations"

When information on the certificate is displayed, check that the content is correct, and then position the cursor over "OK" and press the [Enter] button.

When the message "Digital certificate imported." is displayed, registration is complete.

TOP

Registering a CA Certificate

Procedure

Connect the USB storage device on which the Digital certificate is stored to the projector and start PC Free. The file list screen is displayed.



Press the []] []] []] buttons on the remote control to position the cursor over the CA certificate (CER file) icon and press the [Esc] button.



3

Select "CA certificate" from the menu displayed, then press the [Enter] button.

When information on the certificate is displayed, check that the content is correct, and then position the cursor over "OK" and press the [Enter] button.

When the message "CA certificate obtained. Restart." is displayed, registration is complete. Press the [Enter] button, to turn off the projector. After you press the $[\mathcal{O}]$ button to restart the projector, the certificate is authenticated. If authentication is successful, the IP address is displayed.

78

Troubleshooting



If any of the following problems occur and the indicators do not offer a solution, refer to the pages given for each problem.

Problems concerning network functions

"Cannot connect using EasyMP Network Projection" 🖝 p.80

"When a connection is made using EasyMP Network Projection, the projected image remains as it is, and a connection cannot be made from another computer." 🖝 p.80

"The projector is not found when EasyMP Network Projection is started." 🖝 p.80

"Cannot connect in Advanced Connection Mode or Wired LAN connection" (p.81

"The Slide Show cannot be displayed on the desired display when the multiscreen display function is being executed." 🖝 p.82

"Applications are no longer displayed from the computer screen when the multiscreen display function is executed." 🖝 p.82

"The mouse cursor is not displayed on the computer screen." 🖝 p.82

"The image and sound for movies in EasyMP Network Projection are not displayed, the image is slow to appear, or either the video or audio stop" 🖝 p.83

"No audio from the projector when connecting with EasyMP Network Projection" **p.83**

"When a connection is made using EasyMP Network Projection, a PowerPoint Slide Show cannot be started." 🖝 p.83

"When a connection has been made using EasyMP Network Projection, the screen will not be refreshed when using an Office application." 🖝 p.84

"Error message when starting up EasyMP Network Projection" 🖝 p.84

"Network settings are not restored after cutting the connection to the computer with EasyMP Network Projection." 🖝 p.86

Problems concerning PC Free

"Cannot play back or display files in PC Free" 🖝 p.86

Problems concerning EasyMP Slide Converter

"Error message when starting up EasyMP Slide Converter" 🖝 p.86

"Convert to FSE" is not displayed in the PowerPoint right click menu." 🖝 p.87

Problems concerning monitoring and control

"Mail is not sent even if a problem occurs in the projector." 🖝 p.87





Problems Concerning Network Functions

Cannot connect using EasyMP Network Projection

Check the message on the screen and then apply the following countermeasures.

Error Messages	Remedy
The application version used is not supported. Install the latest	Install the current version of EasyMP Network Projection from the EPSON Projector Software for Meeting &
version of the application on your computer.	Presentation CD-ROM supplied with the projector.

When a connection is made using EasyMP Network Projection, the projected image remains as it is, and a connection cannot be made from another computer.

Check	Remedy
Did the presenter leave the conference room without cutting off the network connection?	With EasyMP Network Projection, the connection with the computer that was previously connected can be cut off when another computer tries to connect with the projector, and it connects with the computer that is trying to connect.
	Therefore, when a Projector keyword is not set for the projector, or if you know the Projector keyword, you can cut off the current connection and, if you perform a connection operation, you can connect to the projector.
	When a Projector keyword is set for the projector, if you do not know the Projector keyword, restart the projector and reconnect.

The projector is not found when EasyMP Network Projection is started.

Check	Remedy
Is the Wireless LAN unit connected?	Check that the supplied or optional Wireless LAN unit is securely connected.
For Wireless LAN	
Is the Network Configuration screen from the Configuration menu displayed on the projector?	When the Network Configuration screen is displayed on the projector, network connection for EasyMP Network Projection is disabled. Close network settings on the projector, and return to the LAN standby screen.
Are the computer's LAN card and the built-in LAN function available?	Check that LAN is valid by checking Control Panel - System - Hardware in the device manager and so on.



Check	Remedy
Is the SSID the same as that of the access point?	Set an SSID that is different from that of the access point. User's Guide "Network Menu (for EB-1925W/1915)"
Quick Connection Mode	
Is the DHCP function for Wired LAN turned On? Quick Connection Mode	Turn Off the DHCP setting for Wired LAN from the Configuration Menu. User's Guide "Network Menu (for EB-1925W/1915)"
Was the network adapter used selected correctly with EasyMP Network Projection?	If the computer has multiple LAN environments, it cannot connect unless the network adapter is selected correctly. When using a computer running Windows, start EasyMP Network Projection, and select the network adapter you are using from Set options - Switch LAN . p.45
For Wireless LAN connection, is the Wireless LAN setting enabled when the computer is in power save mode?	Enable the Wireless LAN.
Are there any obstacles between the access point and the computer or projector?	Sometimes the electromagnetic wave situation prevents the projector from being found in a search. Check for any obstacles between the access point and the computer or projector, and change their position to improve the
For Wireless LAN	electromagnetic wave situation.
Is the computer's Wireless LAN electromagnetic wave set to low?	Set the electromagnetic wave strength to maximum.
Does the Wireless LAN conform to 802.11g, 802.11b, or 802.11a?	It is only compatible with standards 802.11g, 802.11b, and 802.11a, and not with other standards such as 802.11.
Is the firewall turned off, or has the firewall been registered as an exception?	When you do not wish to turn off the firewall or register the firewall as an exception, make the necessary settings to open the ports.
	The ports used by EasyMP Network Projection are "3620", "3621", and "3629".
Is the network cable connected correctly? For Wired LAN	Check that the network cable is connected correctly. Reconnect it if it is not connected or not connected properly.
Is Wireless LAN Power set to Off in the Wireless LAN menu from the projector's Configuration menu? For Wireless LAN	Set Wireless LAN Power to On in the Wireless LAN menu from the Configuration menu. User's Guide "Wireless LAN menu (Only when the supplied or optional Wireless LAN unit is installed)"

Cannot connect in Advanced Connection Mode or Wired LAN connection

Check	Remedy
Is the SSID setting different.	Set the computer, the access point, and the projector to the same SSID.
Is the same WEP key set?	When selecting WEP from Security , set the access point, the computer, and the projector to the same WEP key. <i>User's Guide</i> "Network Menu (for EB-1925W/1915)"



Check	Remedy
Are the connection denial functions, such as <u>MAC Address</u> restrictions and port restrictions, set correctly at the access point?	Set the projector to allow connections from the access point.
Are the IP address, the Subnet Mask, and the Gateway Address for the access point and the projector set correctly?	When not using a DHCP, adjust each setting. User's Guide "Network Menu (for EB-1925W/1915)"
Are the access point and the projector's subnet different?	Select Manual search from EasyMP Network Projection, specify the IP address, and connect. p .39

The Slide Show cannot be displayed on the desired display when the multi-screen display function is being executed.

Check	Remedy
Are you using PowerPoint 2002 or an earlier version? For Windows	To set and use two or more <u>virtual displays</u> , use PowerPoint 2003 or later, or limit the number of virtual displays to one before displaying the Slide Show.

Applications are no longer displayed from the computer screen when the multi-screen display function is executed.

Check	Remedy
Is another application running on the <u>virtual display</u> ? For Windows	When EPSON Virtual Display is installed, another application sometimes runs on the virtual display. In this case, set EPSON Virtual Display to "Off" in "Screen properties".

The mouse cursor is not displayed on the computer screen.

Check	Remedy
Is EPSON Virtual Display installed?	The mouse cursor was moved onto the <u>virtual display</u> . When the virtual display check box is cleared on the
For Windows	Add-Remove EPSON Virtual Display screen, the mouse pointer returns to the screen display area.



The image and sound for movies in EasyMP Network Projection are not displayed, the image is slow to appear, or either the video or audio stop

Check	Remedy
Did you try to play back movies with Media Player or try to operate the screen saver preview?	Depending on the computer, the movie playback screen in Media Player may not be displayed, and the screen saver preview may not be displayed normally.
Is WEP encryption effective, or are multiple projectors connected?	The display speed decreases when WEP encryption is effective or multiple projectors are connected.
Have you enabled DHCP?	When DHCP is set to On in Advanced Connection Mode or Wired LAN connection, if an available DHCP server is not found, it may take some time to enter LAN standby status.
Was EasyMP Network Projection started while a movie was playing, or were the resolution and color number changed? For Macintosh	When playing back movies, start EasyMP Network Projection first before starting play back. If EasyMP Network Projection is started during movie play back and the display screen resolution and color number are changed, try moving the movie playback window, minimizing it, or resizing it and so on.
Is Wireless LAN 802.11g/b being used in Quick Connection Mode?	Depending on the electromagnetic wave environment, there are times when the image and sound for movies may stop. When using the movie sending function, use Advanced Connection Mode or Wireless LAN 802.11a in Quick Connection Mode.
Are you using a computer that does not meet the recommended specifications?	When using a computer that does not meet the recommended specifications, images and audio for movies may stop. <i>User's Guide</i> "Software Requirements (EB-1925W/1920W/1915/1910/1830 only)"

No audio from the projector when connecting with EasyMP Network Projection

Check	Remedy
Are multiple projectors connected to one computer?	Audio can only be transferred to one projector. Try disconnecting other projectors.
Is audio set to output from the computer in Set Options?	Select Output audio from the projector on the Set options Audio Output tab. p.47

When a connection is made using EasyMP Network Projection, a PowerPoint Slide Show cannot be started.

Check	Remedy
Was EasyMP Network Projection started while PowerPoint was running?	When connecting with EasyMP Network Projection, make sure you close PowerPoint first. Slide Show might not run if connecting while PowerPoint is running.
For Windows	

When a connection has been made using EasyMP Network Projection, the screen will not be refreshed when using an Office application.

Check	Remedy
Is the mouse moved continuously?	When you stop moving the mouse cursor, the screen is updated. If the screen does not update quickly, stop moving the mouse cursor.

Error message when starting up EasyMP Network Projection

Error Messages	Remedy
Connection to the projector failed.	Try to connect again. If it still does not connect, check the network settings on the computer and the network settings for the projector.
	For details on the network settings to be made on the projector, see 🖝 User's Guide "Network Menu (for EB-1925W/1915)"
The keyword does not match. Re-enter the keyword displayed on the projector screen.	Check the Projector keyword displayed on the LAN standby screen, and enter the Projector keyword.
The selected projector is busy. Do you want to continue the	You tried to connect to a projector that is connected to another computer.
connection process?	When Yes is clicked, it connects to the projector. The connection between the projector and the other computer is cut off.
	When No is clicked, it does not connect to the projector.
	The connection between the projector and the other computer is maintained.
EasyMP Network Projection initialization failed.	Restart EasyMP Network Projection. If the message still appears, uninstall and then reinstall EasyMP Network Projection.
Connection failed due to keyword mismatch.	When connecting to a projector for which a Projector keyword has been set, the wrong Projector keyword is entered.
	Check the Projector keyword that is displayed on the projector's connection standby screen. After the connection is disconnected and then reconnected, enter the Projector keyword on the keyword entry screen that is displayed.



Error Messages	Remedy
Network adapter information could not be obtained.	Check the following point.
	Is a network adapter installed on the computer?
	Is the driver for the network adapter used installed on the computer?
	After checking, restart the computer and connect again.
	If you still cannot connect, check the following.
	Check the network settings on the computer and the network settings on the projector.
	For details on the network settings to be made on the projector, see 🖝 User's Guide "Network Menu (for EB-1925W/ 1915)"
One or more connected projectors do not support resolutions greater than SXGA. Reduce the screen resolution and reconnect.	There is an ELP-735 projector in the connection destination. Change the computer screen resolution to SXGA (1280x1024) or less.
One or more projectors are not responding.	You cannot connect to multiple projectors simultaneously. Check the network settings on the computer and the network settings on the projector.
	For details on the network settings to be made on the projector, see Cuser's Guide "Network Menu (for EB-1925W/ 1915)"
Enter the keyword displayed on the projector screen.	Check the Projector keyword displayed on the LAN standby screen, and enter the Projector keyword.
Cannot start this application while USB Display is running.	Close USB Display and then start EasyMP Network Projection.
Cannot connect to the projector using this version of EasyMP Network Connection. Install the latest version of EasyMP Network Projection.	This message is displayed when connecting to the projector with EMP NS Connection. To connect, install the current version of EasyMP Network Projection from the EPSON Projector Software for Meeting & Presentation CD-ROM supplied with the projector.
To output audio from the projector, restart applications such as PowerPoint or Windows Media Player.	If one of the following operations is performed when PowerPoint or a media player such as Windows Media Player is running on the computer, restart PowerPoint or the media player to output audio from the projector.
	 Connect the projector with EasyMP Network Projection (When Output audio from the projector is selected from the Set options - Audio Output tab). Select Output audio from the projector from the Set options - Audio Output tab, or click Restore Defaults.
To output audio from the computer, restart applications such as PowerPoint or Windows Media Player.	If one of the following operations is performed when PowerPoint or a media player such as Windows Media Player is running on the computer, restart PowerPoint or the media player to output audio from the computer.
	• Connect the projector with EasyMP Network Projection (When Output audio from the projector is cleared from the Set options - Audio Output tab).
	• Clear Output audio from the projector on the Set options Audio Output tab.
You need to restart your computer to enable Audio Output. Select "Yes" to restart now or select "No" to restart later.	To transfer audio to the projector and play back, select Yes and restart the computer.

85



Error Messages	Remedy
Cannot start this application while Quick Wireless Connection is	Close Quick Wireless Connection and then start EasyMP Network Projection.
running.	

Network settings are not restored after cutting the connection to the computer with EasyMP Network Projection.

Check	Remedy
Are you manually connecting to a Wireless LAN when the computer starts up?	Try connecting to the Wireless LAN manually.
Quick Connection Mode	

Problems concerning PC Free

Cannot play back or display files in PC Free

Check	Remedy
Are you trying to play back a file in a format that is not supported by PC Free?	Depending on the file format, some files cannot be played back in PC Free. For more information on files that can be played back in PC Free, see 🖝 "Files that can be Projected Using PC Free".
Are you using a USB storage device that incorporates security functions?	USB storage devices that incorporate security functions sometimes cannot be used with this projector.
Are you using a USB hard disk or USB card reader?	Some commercially available USB hard disks or USB card readers may not be compatible.

Problems concerning EasyMP Slide Converter

Error message when starting up EasyMP Slide Converter

Error Messages	Remedy
11 / 1	EasyMP Slide Converter cannot be installed under the OS being used. Install under a supported OS. User's <i>Guide</i> "Software Requirements (EB-1925W/1920W/1915/1910/1830 only)"



Error Messages	Remedy
To use EasyMP Slide Converter, PowerPoint® 2002 or a later version must be installed.	Reinstall EasyMP Slide Converter after installing PowerPoint 2002 or later. ☞ p.12
Close PowerPoint®, then convert the file.	When PowerPoint is running, the conversion process may not complete normally. Close PowerPoint, then convert the file.
The file cannot be saved to the specified location. Specify another location and try again.	There are times when you may not be able to save a file such as if you do not have write access to the specified folder. Specify another location and try again.
The file could not be copied to the specified location. Specify another location and try again.	
There is not enough available space in the specified location. Specify another location and try again.	Insufficient free space in the specified drive. Failed to save the file. Make space in the drive so that the file can be saved by deleting any unnecessary files.
The file cannot be copied because there is not enough available space in the specified drive.	Insufficient storage capacity in the drive to transfer scenario. Cannot transfer the scenario. Make space in the drive so that the scenario can be sent by deleting any unnecessary files.
This file cannot be written to the specified location because there is not enough available space.	Cannot write the file to the specified location as there is insufficient free space for a file to which AutoRun is set. Make space so that the file can be written by deleting any unnecessary files.

"Convert to FSE" is not displayed in the PowerPoint right click menu.

Check	Remedy
Was PowerPoint installed after installing EasyMP Slide Converter?	The menu may not be displayed, if PowerPoint is installed after installing EasyMP Slide Converter. Reinstall EasyMP Slide Converter.

Problems Concerning Monitoring and Control

Mail is not sent even if a problem occurs in the projector.

Check	Remedy
Is the Wireless LAN unit connected?	Check that the supplied or optional Wireless LAN unit is securely connected.
For Wireless LAN	
Is the network connect setting correct?	Check the projector's network settings. 🖝 User's Guide "Network Menu (for EB-1925W/1915)"



Check	Remedy
Is Standby Mode set to Network On?	To use the Mail Notification function when the projector is in standby, set Network On in Standby Mode from the Configuration Menu. User's Guide "Extended Menu"
Did a fatal abnormality occur and the projector come to a	When the projector comes to a sudden stop, mail cannot be sent.
sudden stop?	If, after checking the projector, the abnormal status continues, contact your local dealer or the nearest address provided in the Support and Service Guide. 🖝 <i>Epson Projector Contact List</i>
Is power being supplied to the projector?	Check that there has not been a local power failure or that the circuit breaker for the electrical outlet of the projector has not been tripped.
Is the network cable connected correctly?	Check that the network cable is connected correctly. Reconnect it if it is not connected or not connected properly.
For Wired LAN	



This section briefly explains the difficult terms that are not explained in the text of this guide. For details, refer to other commercially available publications.

Ad hoc	A method of Wireless LAN connection that communicates with wireless LAN clients without using an access point. It is not possible to communicate with two or more devices simultaneously.
DPOF	An abbreviation of Digital Print Order Format, this is a format for recording information (photos that you want to print, number of copies, and so on) to print photos taken with a digital camera in recording media such as memory cards.
MAC Address	An abbreviation of Media Access Control. The MAC Address is an ID number unique to each network adapter. A unique number is assigned to each network adapter, and data is transmitted between network adapters based on this identification.
SVGA	A type of video signal with a resolution of 800 (horizontal) \times 600 (vertical) dots that is used by IBM PC/AT-compatible computers.
SXGA	A type of video signal with a resolution of 1,280 (horizontal) \times 1,024 (vertical) dots that is used by IBM PC/AT-compatible computers.
UXGA	A type of video signal with a resolution of 1,600 (horizontal) × 1,200 (vertical) dots that is used by IBM PC/AT-compatible computers.
VGA	A type of video signal with a resolution of 640 (horizontal) × 480 (vertical) dots that is used by IBM PC/AT-compatible computers.
Virtual Display	The screen for one computer is output to multiple displays. A large virtual screen can be created by using multiple displays.
XGA	A type of video signal with a resolution of 1,024 (horizontal) × 768 (vertical) dots that is used by IBM PC/AT-compatible computers.

General Notes

All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by the purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

The contents of this guide may be changed or updated without further notice.

Illustrations in this guide and the actual projector may differ.

General Notice:

Windows Vista and the Windows logo are

trademarks of the Microsoft group of companies.

IBM, DOS/V, and XGA are trademarks or registered trademarks of International Business Machines Corporation.

Macintosh, Mac, and iMac are trademarks of Apple Inc.

Windows, WindowsNT, Windows Vista, and PowerPoint are trademarks or registered trademarks of Microsoft Corporation in the United States.

Other product names used herein are also for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks. TOP

Software Copyright:

This product uses free software as well as software to which this company holds the rights.

©SEIKO EPSON CORPORATION 2009. All rights reserved.

A

Add-Remove EPSON Virtual Display	
	31
Adjust performance	46
Advanced	69
Advanced Connection Mode 16, 17,	19
After converting a file, copy it to memory.	
	69
Animation Transition Time	69
asf	54
Audio Output	47
Automatic search	21
AutoRun File List	71

B

Back to Top	58
bmp	54

С

CA certificate	78
Clear list	
Client certificate	77
Continuous Play (EasyMP Network	
Projection)	28
Continuous Play (EasyMP Slide Converter))
	71
Continuous Play (PC Free)	64
Conversion Mode	68
Convert to FSE	72
Сору	42
Create folder	43
Custom Install	13

D

Digital certificate
Display
on startup
Display order
Display preferences
Display Properties 32
Display properties 32
DPOF 54
Drive 71

E

Easy Install 1	3
EasyMP Network Projection 1	5
EasyMP Slide Converter 6	55
Edit AutoRun 6	57
Edit Complete 6	50
Edit profile 42, 4	1 6
Edit Scenario 5	59
Effect 6	54
Encrypt communications 4	45
Export 4	13

F

File List	71
File list screen	56
fse	54

G

General settings 45

Image	
Import	43

gif 54

pg		54
----	--	----

L

J

Ι

Language	13
Limitations	75

M

Mail Notification	51
Main screen (EasyMP Slide Converter)	
	67
Manual search 21,	39
Mirror Displays	34
Move Files	59
Movie Sending Mode	27
mp4	54
mpg	54
mrk	
Multi-screen display 29,	30

0

Option (PC Free)	64
Output audio from the projector	47

P

PC Free 53	
png 54	
Presentation Mode 26	
Preview 67, 70	
Profile 22, 40	
Projector control 23	
Projector Resolution 69	

Q

Quick Connection Mode	•••••	16, 17, 19
-----------------------	-------	------------

R

Rename	 43
Rename	 43

S

Save in the profile 21,	40
Save to	68
Screen Preview	23
Screen switching time	64
Search method on startup	46
Select Copy Location	
Select drive	
Select target projector	
Set options (EasyMP Network Projection)	
	45
Signal intensity	22
sit	54
Slideshow	63
SNMP	52
SSID	22

Status	21
Switch LAN	46

T

Toolbar	•••••	22
Transfer layered window	•••••	46
Troubleshooting	21,	79

U

Update list	22
Use full-screen video transfer	45
Use multi-display	21

V

Virtual display		30, 31
-----------------	--	--------

W

Web browser	49
Web Control	49
wmv	54