


Home Projector EH-TW3600 EH-TW3200









About the Manuals and Notations Used

Types of Manual

The documentation for your EPSON projector is divided into the following two manuals. Refer to the manuals in the order given below.

Safety Instructions/Support and Service Guide

This manual contains information on using the projector safely, and also includes a guide for warranty service, and a troubleshooting check sheet.

Be sure to read this manual thoroughly before using the projector.

2 User's Guide (this manual)

This User's Guide contains information on installing the projector, basic operations, using the configuration menus, troubleshooting and maintenance.

Notations used in this User's Guide

Safety indications

So that you can use the product safely and correctly, symbols are applied in the User's Guide and on the product to indicate possible harm to the user or to others and the risk of damage to property.

The indications and their meaning are as follows. Make sure you understand them properly before reading the guide.

Marning	This symbol indicates information that, if ignored, could possibly result in death or personal injury due to incorrect handling.
⚠ Caution	This symbol indicates information that, if ignored, could possibly result in personal injury or physical damage due to incorrect handling.

General information

Attention	Indicates procedures where personal injury or damage to the projector may occur if the procedures are not followed correctly.
TIP	Indicates additional information and points which may be useful to know regarding a topic.
Œ	Indicates a page where useful information regarding a topic can be found.
*	Indicates that an explanation of the underlined word or words in front of this symbol appears in the glossary of terms. Refer to the "Glossary" in the "Appendix". \$\sigma p.56\$
(b), Menu etc.	Indicates buttons on the remote control or projector's control panel.
"Menu Name"	Indicates configuration menu items. Example: "Image"-"Color Mode"
[Name]	Indicates the port name of the projector. Example: [Video]

Meaning of "unit" and "projector"


When "unit" or "projector" appears in the text of this *User's Guide*, they may refer to items which are accessories or optional equipment in addition to the main projector unit itself.



Checking the Components

When you unpack the projector, make sure that you have all these components.


If any of the components are missing or incorrect, please contact the place of purchase.







□ Remote control




□ Power cable (3.0m)
Connect to the projector and to a wall outlet.



☐ AA-size alkali batteries (2 pcs.)
Insert into the remote control.

Documentation



- □ Document CD-ROM (Safety Instructions/Support and Service Guide, User's Guide)
- □ Quick Start Guide

Table of Contents



■ Features of the Projector4	Remote control7
■ Part Names and Functions6	Rear8
Front / Top6	Base 8
Control panel6	■ Appearance9
Installing the Projector	
■ Setting up	■ Preparing the Remote Control
Basic Operations	
Turning the power on and projecting images	Focus adjustment
Image Quality Adjustments	
■ Basic Image Quality Adjustments18	■ Examining Image Quality Further23
Selecting the color mode	Sharpness (Advanced) adjustment
Selecting the aspect	Auto Iris (automatic aperture) setting
Advanced Color Adjustments20	■ Viewing Images at a Preset Image Quality (Memory Function)
Hue, saturation, and brightness adjustment20	(Memory Function)24 Saving, Loading, Erasing and
Gamma adjustment20	Renaming Memory24
RGB adjustment (Offset, Gain)22	
Configuration Menu	
■ Configuration Menu Functions26	"Memory" menu
Using the configuration menus26	"Reset" menu
List of configuration menus28	
"Image" menu30	
"Signal" menu31	
"Settings" menu	

Troubleshooting

■ Problem Solving	37
Reading the indicators	37
• When the ▷ 🌡 (warning) indicator is lit or	
flashing	37
• Indicator statuses in normal operation	38

When the indicators provide no help	39
Problems relating to images	39
• Problems when projection starts	43
• Problems with the remote control	44

Table of Contents

Appendix

■ Maintenance	45
Cleaning	.45
• Cleaning the air filter	45
• Cleaning the projector case	46
• Cleaning the lens	46
Consumable replacement periods	.47
Air filter replacement period	47
• Lamp replacement period	47
Replacing consumables	.48
• Replacing the air filter	48
• Replacing the lamp	48
• Resetting the lamp operating time	48


■ Optional Accessories/Consumables	50
■ List of Supported Monitor Displays	51
Component Video	51
Composite Video/S-Video	51
• Computer image (analog RGB)	52
• Input signal from the [HDMI1] / [HDMI2]	
input port	52
■ Specifications	53
■ Glossary	56
■ Index	58

Features of the Projector



Image appearance can be selected to match the projection environment (Color Mode)


The optimum images for the location can be projected simply by selecting the desired color mode from the following five preset modes. \mathcal{F} p.18



If "Natural", "Cinema" or "x.v.Color" is selected, the Epson Cinema Filter effect is applied automatically to increase the contrast and to make skin tones appear with more natural tints.

p.18

Equipped with a wide-angle lens shift function







"x.v.Color" mode realizes more natural color reproduction

This mode is compatible with the extended-gamut color space standard for video (xvYCC). Extended-gamut color images output by equipment supporting this standard are more faithful to the original, and the viewer can enjoy clearer, more natural images. $\triangle p.18$



Sophisticated color adjustment

In addition to the "Color Mode", the absolute color temperature and skin tones can be adjusted by simple procedures to render the picture even more to your own liking. Further, you can adjust gamma, the offset and gain for RGB colors, and the hue, saturation, and brightness of RGBCMY colors, to create colors that match the image. A p.20



Equipped with 2.1x short throw zoom lens

For zoom adjustment, 2.1x short throw zoom lens is provided. Images can be projected onto an 100" screen (16:9 screen only) even at a distance of approximately 3 m. @ p.10



Advanced image quality adjustment functions

Advanced image quality adjustment functions such as "Auto Iris" and "Sharpness (Advanced)" can be used to enjoy even sharper images. With the Auto Iris function turned on, the amount of light can be automatically adjusted to match the images being projected, to create images with depth and perspective. The Sharpness function is used not only to adjust the entire image, but also to emphasize specific regions, such as hair and clothing. **₽** p.23



Other functions to enjoy images more


Some of the other many functions are available as follows.

- EPSON Super White that prevents overexposure in images that are too bright \$\sigma\$ p.32
- The memory function makes it easy to store your preferred color tone settings for projected images into memory, and to load them again. $\triangle p.24$
- Remote control with backlight provides greater visibility and ease of operation in dark rooms. @ p.7
- Auto iris function automatically recognizes changes in the brightness of images to produce natural feelings of depth and stereoscopic effect. p.23

Part Names and Functions



Front / Top




Control panel

indicate problems with the projector.

Buttons with no explanation function in the same way as the corresponding buttons on the remote control. Refer to "Remote control" for further details on these buttons.


Top control panel Side control panel Power button Menu button 🕿 p.26 **₽** p.14, 15 **Esc button** 9 Displays a list of input sources and switches to Esc your desired input source. Lamp Temp <u>-;Ö</u>;- Warning indicator p.37 Enter/Line menu button **button** Flashes or lights in different colors to

Remote control







Rear




Base







* Distance from center of lens to suspension bracket fixing point



Units: mm




Adjusting the projection size

When the projector is further away from the screen, the projection image size are larger.

While referring to the table below, position the projector so that the images are projected onto the screen at the optimum size.

The values should be used as a guide for setting up the projector.




Units: cm

		Projection	n distance		
16:9 screen size		Shortest (Wide)	Longest (Tele)	Α	В
30"	66×37	87	188	17	55
40"	89×50	117	252	23	73
60"	130×75	177	380	35	109
80"	180×100	238	508	46	146
100"	220×120	298	636	58	182
120"	270×150	359	764	69	219
150"	330×190	450	956	86	273
200"	440×250	601	1276	115	364

Units:	cm

		Projection	n distance		
4:3 screen size		Shortest (Wide)	Longest (Tele)	Α	В
30"	61×46	107	231	21	67
40"	81×61	144	309	28	89
60"	120×90	218	466	42	134
80"	160×120	292	623	56	178
100"	200×150	366	779	71	223
120"	240×180	440	936	85	268
150"	300×230	551	1171	106	334
200"	410×300	736	1562	141	446



Set up so that the projector is parallel to the screen. If the projector is set up at an angle to the screen, distortion of the images will occur.

Lens shift adjustment

The lens shift can be used to position the image and the feature is especially useful under the following conditions. $rac{1}{2}$ p.16

- When the projector is suspended from the ceiling
- When the height of the projector does not match with that of the screen
- When the projector is set up to the side so that the screen can be viewed sitting right in front of it

When positioning an image using the lens shift dial, hardly any deterioration of the image occurs because the lens shift correction is adjusted optically. However, for optimal image quality the lens shift function should not be used.




Projection methods

- Warning If you are installing the projector on the ceiling, this projector should be installed by qualified technicians using only approved mounting equipment. If installation work is not carried out correctly, the projector could fall down. This may result in injury or accidents. Contact your dealer to carry out the installation work.
 - If you use a ceiling mount and apply adhesives to the mount to prevent the screws from loosening, or if you use lubricants or oils on the projector, the projector housing may crack and the projector may fall from its ceiling mount. This could cause serious injury to anyone under the mount and could damage the projector. When installing or adjusting a ceiling mount, do not use adhesives to prevent the screws from loosening and do not use oils or lubricants.


Attention

- Do not use the projector in places where there is a lot of humidity or dust, near cooking or heating appliances, or in places where it may come into contact with smoke or steam. Do not use or store this projector outdoors for an extended length of time. Fire or electric shock may result.
- Clean the air filter at least once every 3 months. Clean the air filter more frequently if using the projector in a dusty environment.
- Do not use the projector on its side. This may cause malfunctions to occur.


When projecting from directly in front




When projecting from a ceiling



When projecting from the side of the screen




- * If you place the projector off to the side, aim it straight ahead (rather than at the center of the screen), then use the horizontal lens shift dial to center the image on the screen.
- * When suspending the projector from a ceiling, change the configuration menu settings. @p.34





You can rotate the EPSON logo plate around 180 degrees when suspending the projector from a ceiling.




When one end of the plate is pressed, the opposite end lifts up, so you can pull it out slightly, turn it around and then push it back in.

Connecting Image Sources



Attention

- Turn the power off for both the projector and the signal source before connecting them. If the power for either device is on at the time of connection, damage may result.
- Check the shapes of the cable connectors and the device ports before making the
 connections. If you try to force a connector to fit a device port with a different shape or
 number of terminals, a malfunction or damage to the connector or port may result.



* Use a HDMI cable that conforms to the HDMI specifications.



The cables used will vary depending on the output signals of the video equipment which is being connected.


Some video equipment can output several different types of signal.

Refer to the documentation provided with the video equipment for details on what types of signal the video equipment can output.

Preparing the Remote Control



Inserting batteries into the remote control



Check the (+) and (-) indications inside the battery compartment and insert the batteries so that they face correctly. At the time of purchase, the batteries are not inserted into the remote control. Insert the supplied batteries before using the remote control.


- 1 Lift up the battery cover while pressing its tab.
- 2 Insert the batteries in the correct direction.
- **3** Close the cover.





If delays in the responsiveness of the remote control occur or if it does not operate after it has been used for some time, it probably means that the batteries are becoming flat. When this happens, replace them with new batteries. Have two AA size manganese or alkaline batteries ready. You cannot use other batteries except for the AA size manganese or alkaline.

Using the remote control

Operating range (horizontal)








Starting and Stopping Projection



Turning the power on and projecting images



If there is a problem with projection even though the projector is set up and connected correctly, refer to \$\mathref{p}\$ p.15, 37.



- If you set the "Direct Power On" to "On", the power of the unit will turn on when the main power switch is turned on, without having to press the power button of the remote control or the projector's control panel.

 p.33
- The projector is equipped with the "Child Lock" function that prevents young children from accidentally turning the power on and looking into the lens, and also the "Control Panel Lock" function that prevents mis-operations is available.

 p.33
- This projector is equipped with an automatic adjustment function that automatically optimizes it when a computer input signal is switched.


Exam	ple of output selection
NEC	·
Panasonic	Fn + F3
SOTEC	
HP	Fn + F4
Toshiba	Fn + F5
IBM	
LENOVO	Fn + F7
SONY	
DELL	Fn + F8
Fujitsu	Fn + F10
Macintosh	Set mirror setting or display detection. Depending on OS, you can change the output selection by pressing



When the expected images are not projected


If more than one signal source has been connected, or if no images are projected, use the remote control or the projector's control panel buttons to select the signal source. For video devices, press the [Play] button on the video equipment first, then select the signal source.

Using the remote control



Press the button that has the name of the port on it that the desired signal source is connected to.

Using the control panel





When you press , the menu is displayed.
Each press of moves the pointer. Move the pointer to the target input source to select it.
The input source is automatically switched when no operations are performed about three seconds with placing pointer at the target input source. You can also press fine to switch to the target source.



When the color of the image projected from the [Component] input port is unnatural, select an appropriate signal according to the signal from the device connected at "Input Signal" in the Configuration menu.

p.35

Turning the power off

- 1 Turn the power off for the signal sources that are connected to the projector.
- **2** Press (b) on the remote control or (b) on the projector's control panel.

A standby confirmation message will be displayed, so press (4) or (5) once more.

Power Off?

Yes: Press ® button

No : Press any other button

You can select whether the standby confirmation message is displayed (On) or not displayed (Off) in the Configuration menu.


If it is set to Off, the power will turn off with a single button operation. \mathcal{L} p.34

- 3 When <u>cool-down</u> (approximately 16 seconds) is completed, flashing around the ♂ stops and you can then turn off the main power switch.
 - Simply pressing (b) or (b) does not stop electricity consumption.
- 4 Attach the lens cover.

If the projector is suspended from a ceiling and the lens cover is left removed, the lens cover will still be needed if the projector is moved anywhere, so keep it in a safe place.

Adjusting the Projection Screen





Projection image position adjustment (Lens shift)

If the projector cannot be set up directly in front of the screen, you can use the lens shift function to move the position of the projected images vertically or horizontally within the range shown at right. While turning the lens shift dials, the position where a click is heard is currently at about the middle of the shift range.

The image position cannot be moved to the maximum vertical values and maximum horizontal values at the same time.


Ex) The image cannot be shifted vertically when it has been shifted horizontally by the full amount. When the image has been shifted vertically by the full amount, it can be shifted up to 9% of the horizontal width of the screen.

Standard projection position (center position for lens shift)

Range that the picture can be shifted from the standard projection position


Attention

When transporting the projector, make sure to turn the lens position down by the full amount. Otherwise the lens shift mechanism may be damaged.



Adjusting the tilt of the projector


When an image from the projector that is placed on a flat surface is tilting horizontally (), use the front feet to correct the tilt.



Displaying a test pattern

You can use a test pattern to make the first setup such as zoom, focus, and image position using the lens shift without connecting to any electrical equipment.

If Pattern on the remote control is pressed, the test pattern appears.



To stop displaying the test pattern, press Pattern again.

Basic Image Quality Adjustments



Selecting the color mode



[Color Mode]

Dynamic Living Room

Natural

Cinema

x.v.Color

Press Color Mode and select the color mode from the menu. Setting is also possible using the configuration menu.

Inputting a signal to the HDMI1/HDMI2 terminals.



Blank

Pattern


EPSON

Select Menu Operations

Use to select an item. Press (enter) to confirm the selection.

*If you press Esc , the Select menu disappears.

Selecting the aspect →



Press Aspect and select the aspect mode from the menu.

When 720p, 1080i or 1080p signals are being input to the [HDMI1], [HDMI2] or [Component] input port, the aspect setting is fixed at "Normal" and cannot be changed.

If you project an image that is compressed, enlarged or separated using the aspect function in public places such as a store or hotel for the purposes of profit-making or public display, it may result in infringing on the author's right that is protected by copyright law.

- When projecting using Auto

- For 4:3 input signals → Normal
- For input images recorded → Full in squeeze mode
- For letterbox input signals → Zoom
- This is not available for when image signals are being input from a computer and for some component video → signals.
- If Auto is not suitable, the setting will become Normal.



Dynamic

: Ideal for using in a bright

Living Room

: Ideal for using in a bright room. Provides clear and crisp images with vivid colors.

Natural

: Ideal for using in a dark room. It is recommended that you start in this mode when making color adjustments.

Cinema

- : Ideal for watching movies and concerts in a dark room.
- x.v.Color
- EYou can select from either of the signals being input to the HDMI1 and HDMI2 terminals. If this is used when viewing images which have been recorded in the x.v.Color standard, a true natural color representation will be obtained.

 P.4

When the mode is selected, the EPSON cinema filter is automatically applied and the original colors of the image source are reproduced more exactly.


Input signal	Images with standard aspect ratio (4:3)Computer images	Images recorded by a video camera or DVD software in squeeze mode	Letterbox images	Images with standard aspect ratio (4:3)
Recommended aspect mode	Normal	Full	Zoom	Wide
Result	Black bands will appear at the left and right of the images.	Input signals will be projected at the same width as the projector's panel resolution.	Input signals will be projected at the same height as the projector's panel resolution.	Input signals will be projected at the same height as the projector's panel resolution. At this time, the image enlargement ratio
Remarks	When HDTV images are projected, the images appear in 16:9 size.	When 4:3 images are projected, the images will be elongated horizontally.	●When a 4:3 image is projected, the top and bottom of the image are hidden from view. If this happens, the part of the image hidden from view at the top and bottom can be reduced in size in the vertical direction so that it can be viewed by "Zoom Size" in the Configuration menu. ■ p.31 ●When images with subtitles are projected and the subtitles are truncated, use the "Zoom Caption Pos." menu command to adjust. ■ p.31	will be smaller near the middle of the images but become larger towards the left and right edges of the images. This is useful for when 4:3 images are projected onto a wide screen. Because there is almost no distortion due to enlargement in the middle of the images, the images appear close to what they would be at their original size. And because both ends of the images are enlarged, movement at the edges of the images appears faster and gives an impression of greater speed, making it ideal for viewing sporting events.

Advanced Color Adjustments




You can select "Sharpness" or "Advanced" in the "Image" menu to adjust the images according to your own preferences. The adjustment screens for "Gamma" and "RGBCMY" can be displayed on the screen directly by pressing the corresponding buttons on the remote control.

The adjustment values can be stored in the memory so that you can retrieve them and apply them to the projected images at any time. (p.24)




Hue, saturation, and brightness adjustment



The hue, saturation, and brightness for each of the R (red), G (green), B (blue), C (cyan), M (magenta) and Y (yellow) color components can be adjusted. Adjustment is not possible when "Color Mode" is set to "x.v. Color".

Gamma adjustment



Differences between equipment may result in a slight variation in the coloring when images are projected, and you may want to adjust this. (Projection will stop temporarily during such adjustment.) There are two methods of doing so. One is to select one of the gamma correction values [2.0], [2.1], [2.2], [2.3], [2.4]. The other is customized adjustment, which is done with reference to the projected image or a gamma graph. The gamma graph's horizontal axis represents the input signal level and its vertical axis the output signal level.

Adjustment is not possible when "Color Mode" is set to "x.v. Color".

Adjusting from the gamma correction values

Use or or (UP or DOWN) to select the correction value that suits the connected equipment and your own preferences from "2.0", "2.1", "2.2", "2.3" or "2.4", and then press (Enter) or (Enter) to confirm the selection.

Observe the gamma graph to check the result of the adjustment.

When a smaller value is selected, the dark areas of images become brighter, but the lighter areas may become oversaturated. This is indicated by bulging in the upper portion in the gamma graph.

When a larger value is selected, the bright areas of images become darker. This is indicated by bulging in the lower portion in the gamma graph.

Hue

Adjusts the tone of the entire image to bluish, greenish and reddish.


Saturation

Adjusts the overall vividness of the images.

Brightness

Adjusts the brightness of the overall image.

Use or or (UP or DOWN) to select and confirm the color, and then select either "Hue", "Saturation" or "Brightness" and then use (I) or (LEFT or RIGHT) to make the adjustment.



To adjust another color, press Esc..

To return the adjustment results to their default settings, press (Default).

2 Press (RGBCMY) to exit the menu.


■ Customized ("Adjust it from the image")

Use or or (UP or DOWN) to select "Customized" - "Adjust it from the image" in that order, and then press (Enter) or (Enter) to confirm the selection

A gamma icon will appear in the projected image.



Use or to move the gamma icon to the place where you want to adjust the brightness, and press for or to confirm the selection. The place selected and the regions of the same brightness will flash, and a gamma graph will appear.



Use or or (UP or DOWN) to make the adjustment, and then press (enter) or (enter) to confirm the adjustment. Press (Default) to go back and do it again.


Customized ("Adjust it from the graph")

Use or or (UP or DOWN) to select "Customized" - "Adjust it from the graph" in that order, and then press (enter) or (enter) to confirm the selection.

A gamma adjustment graph will appear.



Use (()) or [-]-(LEFT or RIGHT) to select the place where you would like to adjust the brightness of the color tone.



Use or or (UP or DOWN) to make the adjustment, and then press (Inter) or (Inter) to confirm the adjustment. Press (Default) to go back and do it again.



RGB adjustment (Offset, Gain)

The image brightness can be adjusted by adjusting the individual R (red), G (green) and B (blue) components of the dark areas (offset) and bright areas (gain).

Adjustment is not possible when "Color Mode" is set to "x.v. Color".


■ Offset

If you would like dark areas to appear more clearly, change the setting to the + (right) side. If you change it to the – (left) side, the whole image will become sharper, but the contrast in dark areas will become poorer.

■ Gain

If you would like bright areas to appear more clearly, change the setting to the – (left) side. If you change it to the + (right) side, you will feel that the image is becoming brighter and closer to white, but the contrast in light areas will become poorer.

Press Menu and then select "Image" - "Advanced" - "RGB" in that order and confirm the selection.



2 Use or or (UP or DOWN) to select an item, and then use (LEFT or RIGHT) to make the adjustment.

To return the adjustment results to their default settings, press (Default).

3 Press Menu to exit the menu.

Examining Image Quality Further



In addition to color adjustments, adjustments to advanced sharpness and the amount of light from the lamp can also be made to match the image in search of the best picture.

Sharpness (Advanced) adjustment


If "Thin Line Enhancement" is set in the + direction, hair and the detailed areas of clothing will be emphasized.

If "Thick Line Enhancement" is set in the + direction, the areas emphasized by "Thin Line Enhancement" will be hardly emphasized. Instead, the rough areas of the entire subject, such as contour and background, will be emphasized, resulting in a sharp image.

Setting "Horiz. Line Enhancement" / "Vert. Line Enhancement" to the + side will enhance the image sharpness in the horizontal / vertical direction. Setting them to the - side will give a soft image.

This cannot be adjusted during input of computer image signals.

Press Menu, and then select "Image" - "Sharpness". Select "Advanced" at the top-right corner of the screen to confirm the selection.




- Use or (UP or DOWN) to select a menu item, and use (UP) or (LEFT or RIGHT) to make adjustments. You can adjust "Thin Line Enhancement" and "Thick Line Enhancement" at the same time by using the bar on the top in the screen. To return the adjustment results to their default settings, press (Default).
- 3 Press Menu to exit the menu.

By pressing Sharpness on the remote control, you can directly display the sharpness setting ("Standard"/"Advanced") screen just as selected using "Sharpness" of the "Image" menu.

Auto Iris (automatic aperture) setting

When "Auto Iris" is on, the light intensity from the lamp is automatically controlled according to the brightness of images, and you can get higher contrast and rich images. Tracking speed of the light intensity control in response to changes in brightness of images can be set to either "Normal" or "High Speed" depending on your preference. Setting is not possible when "Color Mode" is set to "x.v. Color."

* An operation sound of Auto Iris function may be emitted while projecting some images. This is not a failure of the projector. Press Menu, and then select "Image" - "Auto Iris".




- 2 Select "Normal" or "High Speed" to confirm the selection.
- **3** Press Menu to exit the menu.

Viewing Images at a Preset Image Quality (Memory Function)

After using a subset of "Signal" and "Image" in the configuration menu to adjust the projected images, the adjusted values can then be saved (Save Memory).


In addition, the saved data can be retrieved easily, so that you can enjoy viewing images with the adjusted settings at any time (Load Memory).



Save Memory

- Adjust each of the settings to the values to be saved.
- **2** Press Memory, and select "Save Memory".

The Save Memory screen is displayed.



3 Select the memory name to register the adjustments to from Memory1 to 10, and press [Enter].

When preceding the memory name is green, this indicates that adjustments are already saved to memory.

Select an already saved memory name, and press (Enter) or (Enter).

A confirmation message will be displayed. If you select "Yes", the previous memory content is erased, and the current adjustment values are saved.

Load Memory

Load saved memories.

- Press Memory, and select "Load Memory".
- The Load Memory screen will be displayed.
- **2** Select the target memory name.



- The color mode selected when the memory was registered is displayed on the right side.
- Some settings retrieved from memory may not be applied to the images depending on the input signal.

Erase Memory

This feature can be used to erase and clean up unwanted memories.

- Press Memory, and select "Erase Memory".

 The Erase Memory screen will be displayed.
- 2 Select the memory name to erase.

A confirmation message will be displayed. If you select "Yes", the memory will be erased.

Configuration Menu Functions




The configuration menus can be used to make a variety of adjustments and settings involving image quality and input signals.

The following two types of menu are available.

■ Full menu

All items in the configuration menu can be checked while the settings are being made.



■ Line menu

Some of the items in the "Image" menu in the Configuration menu can be adjusted.

This menu is useful for viewing the effects of adjustments in the images being projected while the adjustments are being made.



For details on the operation method, refer to "Using the configuration menus" in the next section.




The Configuration menu can be used to change the color pattern and display position of the menus.

Using the configuration menus

1 Displaying a menu





Line menu: Press (Enter) or [Enter].





2 Selecting a menu item

Use or to select a menu item, then press (Enter).

3 Changing settings

Example:





Use $\stackrel{\textstyle \longleftarrow}{}$ or $\stackrel{\textstyle \longleftarrow}{}$ to select an item, then press $\stackrel{\textstyle \stackrel{\textstyle \longleftarrow}{}}{}$.

If you press when an item with **②** next to it is selected, the selection screen for that item will be displayed.

To return to a previous display, press (ESC).



- For items such as "Brightness" which can be adjusted using an adjustment bar, the adjustment values can be reset to the default if you press Default while the adjustment bar is being displayed.
- If Blank on the remote control is pressed while a menu is being displayed, the menu screen disappears. This is useful for checking your adjustment result on the images. If you press Blank once more, the menu is displayed again.


4 When setting is complete


Press Menu.



List of configuration menus

When no image signals are being input, the "Image" menu and the "Signal" menu cannot be adjusted. Also, the items displayed in the "Image" menu, the "Signal" menu and the "Info" menu will vary depending on the type of image signals that are being projected.







"Image" menu

Not displayed when image signals are being input from a computer.

Color Mode *1

Five different settings can be selected for the Color Mode, to match the images being projected or the projection environment. p.18

Brightness *2

(Adjustment is not possible when "Color Mode" is set to "x.v. Color".)

Adjust this when the output level of the connected equipment is weak and you feel that images are dark.

Contrast ^{→ *2}

(Adjustment is not possible when "Color Mode" is set to "x.v. Color".)

Adjusts the difference between bright and dark areas.

When the contrast is increased, images with greater modulation are obtained.

Color Saturation *2

(Adjustment is not possible when "Color Mode" is set to "x.v. Color".)

This adjusts the color intensity for the images.

Tint *2

(Adjustment is not possible when "Color Mode" is set to "x.v. Color".)

This adjusts the image tint.

Sharpness *2

This adjusts the image sharpness.

Standard

The adjustment results are applied to the entire image.

Advanced

This can be used to adjust a specific region.
p.23

Abs. Color Temp.*2

(Adjustment is not possible when "Color Mode" is set to "x.v. Color".)

This adjusts the overall tints of the images. If you select a higher value, images appear bluish, and if you select a lower value, images appear reddish. The absolute color temperature can be set to one of 12 settings within the range of 5000K to 10000K.

Skin Tone *2

(Adjustment is not possible when "Color Mode" is set to "x.v. Color".)

This adjusts the skin tones of people who appear in the images. If you select a higher value, green tone is increased, and if you select a lower value, red tone is increased.

Advanced

(When "Color Mode" is set to "x.v.Color", these adjustments are not possible except for "Super-resolution".)

Gamma 1

This adjusts gamma. You can select a value, or make adjustments while viewing an image or a graph.
p.20

RGB *1

This lets you adjust the offset and gain for each of the R/G/B color components. 🕿 p.22

^{*1} The setting values are stored separately for each image source and signal type.

^{*2} The setting values are stored separately for each image source and color mode setting.



	(does not appear when signals from the [HDMI1] /[HDMI2] input port are being input
	(*************************************

RGBCMY *1

This lets you adjust the hue, saturation, and brightness for each of the R/G/B/C/M/Y color components. \nearrow p.20

Power Consumption*2

This lets you set the lamp brightness to one of two settings.

Set to "ECO" if the projection images are too bright when projecting in a dark room or projecting onto a small screen. When used at the "ECO" setting, the power consumption and fan noise during projection is reduced.

Auto Iris ^{*3}

(Setting is not possible when "Color Mode" is set to "x.v. Color.")

Tracking speed of the light intensity control in response to changes in brightness of images can be set to either "Normal" or "High Speed" depending on your preference. If set to "Off", no light intensity control is performed. \$\sigma\$ p.23

Reset

This returns all settings in the "Image" menu to their default settings.

"Signal" menu

Aspect ^{→ *1}

Selects the aspect mode. 🕿 p.18

Zoom Size *1

This can be set only when "Aspect" is set to "Zoom".

This function enables the image to be reduced in size in the vertical direction so that the top and bottom of images that are hidden from view can be viewed when "Zoom" is set. The larger the adjustment value (reduction ratio) set here, the more the image is compressed and displayed squashed in the vertical direction.

Zoom Caption Pos. *1

This can be set only when "Aspect" is set to "Zoom".

This function moves the display position of the image in one direction, up or down, to display captions when projecting images with captions.

Tracking [▶] *1

(This can be adjusted only when analog RGB image signals are being input.)

This adjusts the images if vertical stripes appear in the images.

Sync. » *1

(This can be adjusted only when analog RGB image signals are being input.)

This adjusts the images if flickering, fuzziness or interference appear in the images.

- Flickering and fuzziness may also occur when the brightness, <u>contrast</u> and sharpness settings are adjusted.
- Clearer adjustments can be obtained if you adjust the "Tracking" first and then adjust the "Sync".

^{*1} The setting values are stored separately for each image source and signal type.

^{*2} The setting values are stored separately for each image source and color mode setting.

^{*3} The setting values are stored separately for each color mode setting.



Not displayed when image signals are being input from a computer.
Only displayed for Computer image input (does not appear when signals from the [HDMI1] /[HDMI2] input port are being input)

Position

(Setting is not possible when signals are being input from the [HDMI1] /[HDMI2] input port.) When part of the image is clipped, move the image display position vertically and horizontally so that the entire image is projected. Press , , , and (to adjust the position.

Progressive[→]*

(This can be set only when signals are being input from the [Video] / [S-Video] input port, or 480i, 576i, 1080i signals are being input from the [HDMI1] / [HDMI2] / [Component] input port.)

<u>Interlace</u> (i) signals are converted to progressive (p) signals using a method appropriate for the image.

- Off :This is ideal for using when viewing images with a large amount of movement.
- Video :This is ideal for general video images.
- Film/Auto :Optimum conversion is performed for movie, computer graphics, and animation input signals.

Motion Detection

(This can be set only when signals are being input from the [Video] / [S-Video] input port, or 480i, 576i, 1080i signals are being input from the [HDMI1] / [HDMI2] / [Component] input port.)

Select whether the progressive conversion operation mode is for fast-moving images or for slow-moving images. The smaller the value, the more suitable the mode is for viewing still images. The larger the value, the more suitable the mode is for viewing video images.

2-2 Pull-down

(This setting can be made only when a 1080p/24Hz signal is being input to the [HDMI1] / [HDMI2] / [Component] input terminals.)

For a 1080p/24Hz input signal, you can select between 2-2 pull-down projection or 2-3 pull-down projection. Selecting "On" sets the 2-2 pull-down.

Auto Setup

This sets automatic adjustment to on or off in order to set whether the projector automatically adjusts images to their optimum condition when the input signal is changed. The three automatically adjusted items are "Tracking", "Position" and "Sync."

Advanced

Noise Reduction

This reduces flickering of images.

Three modes are available. Select the mode to suit your liking.

Set "Off" when the image source, such as DVD, contains little electrical interference.

Setup Level

(This can be set when <u>NTSC</u> signals or <u>component video</u> signals are being input from the [Video]/[S-Video] input port.)

If using products designed for destinations such as South Korea that have different black level (setup level) settings, use this function to obtain correct images. Check the specifications of the connected equipment when changing this setting.

EPSON Super White

(This can only be adjusted when the color mode is set to "Natural" or "Cinema" and signals are being input via the [HDMI1]/[HDMI2] input ports.)

If bright white areas of images appear uneven and overexposed, set to "On".

When set to "On", the "HDMI Video Range" setting will be ignored.

^{*} The setting values are stored separately for each image source and signal type.

Not displayed when image signals are being	g input from a computer
--	-------------------------

Overscan²

(Setting is possible only when signals are being input from the [HDMI1]/[HDMI2]/[Component] input port.)

This changes the display area (the part of projected images).

- Off, 2%, 4%, 6%, 8%: If set to "Off", the top and the bottom of the image are sometimes affected by electrical interference depending on the image signal. In such cases, try to adjust the display position ("Position").
 p.32
- Auto: Displayed when the signals from [HDMI1] / [HDMI2] input port are being input. This is automatically set to Off or 8%, depending on the input signal. (Not displayed when the equipment's DVI port is connected to the projector's [HDMI1] / [HDMI2] input port.)

HDMI Video Range

(Setting is possible only when "EPSON Super White" is "Off". Setting is not possible, however, when "Color Mode" is set to "x.v. Color.")

When the [HDMI1] / [HDMI2] input port of the projector is connected to a DVD player, for example, setting this to Auto allows the projector to automatically determine and set the video range of the input signal.

If this is set to Auto and a blackout/whiteout condition occurs, set the video range of the projector to match that of the DVD player. The setting on the DVD player can be either Normal or Expand.

Note that if the equipment's DVI port is connected to the projector's [HDMI1] / [HDMI2] input port, Auto is not displayed.

Reset

All the adjustment values on the "Signal" menu, except "Aspect[▶]", are returned to their default values.

* The setting values are stored separately for each image source and signal type.

"Settings" menu

Direct Power On

When set to "On" with the main power switch left on, be aware that sudden surges of electricity that may occur when the power comes back on after a power outage may cause the projector to turn on.

Sleep Mode

The projector is equipped with a power-saving function that causes the power to turn off automatically and the projector to switch to standby if no signal is input to the projector for a continuous length of time. The length of time before the power-saving function operates can be selected from four available settings. If "Off" is selected, the power-saving function will not operate.

If you press (b) while the projector is in standby mode, projection will start again.

Child Lock

This locks the power on function of the button on the projector's control panel, so that a child cannot accidentally turn the projector's power on and look into the projector's lens. When the lock is applied, the power will only turn on if bis pressed down for about 3 seconds. can be used to turn off the power, and the remote control will continue to operate as normal.

If you change the setting, the new setting will take effect after the power has been turned off and the $\underline{\text{cool-down}}^{\flat}$ period is complete.

Even if "Child Lock" is set to "On", be aware that projection starts merely by turning the main power switch on when "Direct Power On" is set to "On".



Control Panel Lock

If this is set to "On", you can't operate the projector's control panel buttons and a ficon appears on the screen when a button is pressed. To cancel, press and hold to the projector's control panel for about seven seconds or more.

If you change the setting, the new setting will take effect after exiting the configuration menu.

Trigger Out

This sets the trigger out function which communicates information such as the power on status of the projector to external equipment.

If you change the setting, the new setting will take effect after the power has been turned off and the $\underline{\text{cool-down}}^{\triangleright}$ period is complete.

High Altitude Mode

A fan is set at a certain speed of rotation so as to bring down internal temperature.

When using above an altitude of about 1500m, set to "On".

Projection

This should be set in accordance with the method used to set up the projector.

- Front : Select when the projector is set up in front of the screen.
- Front/Ceiling: Select when the projector is set up in front of the screen and suspended from a ceiling.
- Rear : Select when the projector is set up behind the screen.
- Rear/Ceiling: Select when the projector is set up behind the screen and suspended from a ceiling.

Illumination

If the light from or seconds becomes bothersome while watching a movie or the like in a dark room, turn this setting to "Off".

Display

Menu Position

Press , , and to specify the position for the menus to be displayed.

Menu Color

Selects the color for the main configuration menu.

- Color 1:Black
- · Color 2:Blue

Messages

This sets whether the following message displays appear (On) or don't appear (Off).

- Image signal, color mode, aspect and item name when memory settings are retrieved.
- Messages such as when no image signals are being input, when an incompatible signal is input, and when the internal temperature rises.

Display Background

Displays a menu for selecting the screen status for when using the blank function or when no image signal is input.

Startup Screen

This sets whether the start-up screen (the image that is projected when projection starts) is displayed (On) or not displayed (Off).

If you change the setting, the new setting will take effect after the power has been turned off and the $\underline{\text{cool-down}}$ period is complete.

Standby Confirmation

Sets whether the standby confirmation message is displayed (On) or not displayed (Off).

Input Signal

Video Signal

Sets the signal format in accordance with the video equipment that is connected to the [Video] or [S-Video] input port. If set to "Auto", the video signal format is set automatically.

If there is a lot of interference in the image, or if a problem such as no image being projected occurs even though "Auto" has been selected, select the correct signal format manually.

Component

Change this setting depending on the type of signal that is being output from the video equipment that is connected to the [Component] input port.

If "Auto" is selected, appropriate signal is automatically set. If colors appear unnatural even though "Auto" is selected, select appropriate signal name in the menu.

Language

This sets the display language for messages and menus.

Reset

Adjustment values for the "Settings" menu functions are returned to their default settings, except for the "High Altitude Mode", "Projection", "Component", and "Language".



"Memory" menu

Load Memory

This retrieves settings previously saved using "Save Memory".

p.24 This cannot be selected when nothing is saved at "Save Memory".

Save Memory

This can be used to save "Image" menu settings. @ p.24

Erase Memory

This is used to erase unwanted saved memory.
p.25

"Reset" menu

Reset All

This resets all configuration menu settings to their default settings. "Component" and "Language" in the "Settings" menu, and the settings of "Memory" menu are not returned to their default even if "Reset All" is executed.

Reset Memory

This resets (erases) all settings that have been made using the "Save Memory".

Reset Lamp Hours

Clear the cumulative lamp operating time and reset to "0H". Perform this procedure when you replace the lamp.




Reading the indicators

The projector indicates its status using the indicators.

(the icon and the around the button) and (the icon) light and flash, and lights and flashes in red according to the current status.


The following tables show what the indicators mean and how to remedy the problems that they indicate.

* If all indicators are switched off, check that the power cable is connected correctly and that the main power switch is on.



When the ☼▮ (warning) indicator is lit or flashing warning/problem

•: Lit -: Flashing 0: Off



Internal problem

Fan problem / Sensor problem

Attention

Disconnect the power cable from the electrical outlet. Then contact your local dealer or the nearest address provided in the Support and Service Guide. © Epson Projector Contact List



0

Red

-)@(-

-<u>ˈ</u>Ö;-

Lamp problem / Lamp on error

Check if the lamp is broken. \triangle p.48 Clean the air filter. \triangle p.45

If the lamp is not broken

Replace the lamp and then turn the power on. If the problem is still not solved after the lamp is replaced, stop using the projector and disconnect the power cable from the electrical outlet. Then contact your local dealer or the nearest address provided in the Support and Service Guide. Fepson Projector Contact List

If the lamp is broken


Contact your local dealer or the nearest address provided in the *Epson Projector Contact List*.

When using above an altitude of about 1500 m, make sure you set the "High Altitude Mode" to "On". \mathscr{F} p.34



High internal temperature (overheating)

The lamp will switch off automatically and projection will stop. Wait for approximately 5 minutes. When the cooling fan stops, turn off the main power switch at the rear of the projector.



You can continue using the projector, but if the temperature rises again, it will switch off automatically.

- If the projector is installed against a wall, leave a space of 20 cm or more between it and the wall.
- Clean the air filters if they are blocked.
 p.45

If the problem is not solved when the power is turned back on, stop using the projector, turn off the main power switch, and disconnect the power cable from the electrical outlet. Then contact your local dealer or the nearest address provided in the Support and Service Guide. Fepson Projector Contact List



37





Lamp replacement warning

It is time to replace the lamp. Replace the lamp with a new one as soon as possible.

p.50 If you continue to use the projector without replacing the lamp, the lamp may blowout.

Indicator statuses in normal operation (b)/€: Lit : Flashing During normal operation, the 💆 🌡 indicator is off. Standby condition If you press (b), projection will start after a brief interval. Ф Warm-up in progress Warm-up time is approximately 30 seconds. Power off operations are ignored while warm-up is in progress. € **Projection in** டு progress Normal operation is in progress. Ð Remote control and control panel are disabled while cool-down is in Cool-down[▶] in progress. Once cool-down is complete, the projector turns to stand-by progress mode. If the main power switch at the rear of the projector is turned off (Approx. 16 while cool-down is still in progress, wait until the lamp has cooled seconds) down sufficiently (approximately 10 minutes is required), and then turn the main power switch back on.



When the indicators provide no help

If any of the following problems occur and the indicators do not offer a solution, refer to the pages given for each problem.

Problems relating to images

■No images appear
p.39

Projection does not start, the projection area is completely black, the projection area is completely blue, etc.

Moving images are not displayedp.40

Moving images played on computer are not displayed.

- The message "Not Supported" is displayed p.40
- ■Images are fuzzy or out of focus
 p.41
- ■Interference or distortion appear in images p.41

Problems such as interference, distortion or black & white checked patterns appear.

■ Image is truncated (large) or small p.42

Only part of the image is displayed.

■ Image colors are not right

p.42

The whole image appears purplish or greenish, images are black & white, colors appear dull, etc.

(Computer monitors and LCD screens have different color reproduction performance, so that the colors projected by the projector and the colors appearing on the monitor may not necessarily match, but this is not a sign of a problem.)

- Images appear dark p.43
- Projection stops automatically p.43

Problems when projection starts

■ Power does not turn on p.43

Problems with the remote control

The remote control does not work p.44

Problems relating to images

■ No images appear

Have you pressed the [Power] button?	Press (b) on the remote control or (c) on the projector's control panel.
Is the main power switch turned off?	Turn on the main power switch at the rear of the projector.
Are all of the indicators switched off?	Disconnect the power cable and then reconnect it. p.14 Check the circuit breaker to see if power is being supplied.
Is blank mode active?	Press Blank on the remote control to cancel the blank function.
Is a video signal being input?	Check that the power for the connected equipment is turned on. If the "Messages" menu command has been set to "On", messages relating to the image signals will be displayed. Settings" - "Display" - "Messages" p.34



Are the image signal forma	at
settings correct?	

If a <u>composite video</u> or <u>S-Video</u> signal is being input If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source.

Settings" - "Input Signal" - "Video Signal" p.35

If the signal source is connected to the [Component] input port If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment.

☞ "Settings" - "Input Signal" - "Component" p.35

Have the configuration menu settings been made correctly?

Try resetting all of the current settings. @ p.36

Were the projector and computer connected while their power was already turned on?

When a computer is connected

If the connection is made while the power is already turned on, the function [Fn] key that switches the computer's video signal to external output may not work. Turn the power for the computer that is connected to the projector off and then back on again.

Moving images are not displayed

Is the computer image signal set to output simultaneously both externally and to the LCD monitor?

Only when projecting images from a laptop computer or computer with a built-in LCD screen

When attempting to display images simultaneously on an external monitor and an LCD monitor, moving images may not be displayed due to specifications of the computer. Set the image signal to output only externally.

© Computer documentation, under a title such as "External output" or "Connecting an external monitor"

■ The message "Not Supported" is displayed

Are the image signal format settings correct?	If a <u>composite video</u> or <u>S-Video</u> is being input If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source. Settings" - "Input Signal" - "Video Signal" p.35
	If the signal source is connected to the [Component] input port If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment. "Settings" - "Input Signal" - "Component" p.35
Does the mode match the	Use the "Resolution" menu command to check the signals being

Does the mode match the frequency and resolution of the image signals?

Only when projecting computer images

Use the "Resolution" menu command to check the signals being input, and check the "List of Supported Monitor Displays" to make sure that the signals are compatible.

☞ "Info" - "Resolution" p.29

■ The message "No Signal" is displayed

Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. p.12
Has the correct video input port been selected?	Press HDMI1, HDMI2, Component, PC, S-Video or Video on the remote control or on the projector's control panel to change the image source. p.15
Is the power for the connected equipment turned on?	Turn the power on for the devices.
Are the image signals being output to the projector?	If the image signals are only being output to the computer's LCD monitor, you need to change the output.
Only when projecting images from a laptop computer or computer with a built-in LCD	For some computer models, when the image signals are output externally, they no longer appear on the LCD monitor. © Computer documentation, under a title such as "External output" or "Connecting an external monitor"
screen	If the connection is made while the power is already turned on, the function [Fn] key that switches the computer's video signal to external output may not work. Turn the power for the projector and the computer off and then back on again. p.14

■ Images are fuzzy or out of focus

Has the focus been adjusted correctly?	Adjust the focus. p.16
Is the lens cover still attached?	Remove the lens cover.
Is the projector at the correct distance?	The recommended distance from the projector to the screen is within 87 to 1276 cm for a screen size of 16:9, and 107 to 1562 cm for a screen size of 4:3. Set up the projector so that the projection distance is within this range. p.10
Has condensation formed on the lens?	If the projector is suddenly taken from a cold environment to a warm environment or if sudden ambient temperature changes occur, condensation may form on the surface of the lens, and this may cause the images to appear fuzzy. Set the projector up in the room approximately one hour before it is to be used. If condensation forms on the lens, turn off the projector, disconnect the power cable and wait for the condensation to disappear.

■ Interference or distortion appear in images

Are the image signal format settings correct?	If a <u>composite video</u> or <u>S-Video</u> is being input If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source. Settings" - "Input Signal" - "Video Signal" p.35
	If the signal source is connected to the [Component] input port If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment. "Settings" - "Input Signal" - "Component" p.35
Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. p.12



Is an extension cable being used?	If an extension cable is used, interference may increase. Try connecting a signal amplifier.
Have the "Sync." and "Tracking" settings been adjusted correctly? Only when projecting computer images	The projector has an automatic adjustment function that causes the optimum images to be projected. However, for some types of signal, the correct adjustments may not be obtained even after automatic adjustment is carried out. In such cases, use the "Tracking" and "Sync." menu commands to make the adjustments. Signal" - "Tracking", "Sync." p.31
Has the correct resolution been selected? Only when projecting computer images	Set the computer so that the signals that are output are compatible with this projector. "List of Supported Monitor Displays" p.51 Computer documentation

■ Image is truncated (large) or small

Has the correct <u>aspect</u> [→] been selected?	Press Aspect to select the aspect that corresponds to the input signal. Pp.18 If images with subtitles are being projected using "Zoom", use the "Zoom Caption Pos." menu command to adjust the images. Press Aspect to select the aspect that corresponds to the input signal.
Has the "Position" setting been adjusted correctly?	Use the "Position" the menu command to make the adjustment. "Signal" - "Position" p.32
Has the computer been set for dual display? Only when projecting computer images	If the dual display setting has been activated by the connected computer, only half of the images on the computer screen is displayed by the projector. To display the whole of the image on the computer screen, turn off the dual display setting. © Computer video driver documentation
Has the correct resolution been selected? Only when projecting computer images	Set the computer so that the signals that are output are compatible with this projector. "List of Supported Monitor Displays" p.51 Computer documentation

■ Image colors are not right

Are the image signal format settings correct?	If a <u>composite video</u> or <u>S-Video</u> is being input If projection does not occur when the "Video Signal" menu command is set to "Auto", select the signal format that matches the signal source. Settings" - "Input Signal" - "Video Signal" p.35
	If the signal source is connected to the [Component] input port If projection does not occur when the "Component" in the "Input Signal" menu command is set to "Auto", set the signal format that matches the signal that is being projected from the connected equipment. "Settings" - "Input Signal" - "Component" p.35
Are the cables connected correctly?	Check that all of the cables required for projection are securely connected. p.12
Has the image contrast been adjusted correctly?	Use the "Contrast" menu command to adjust the color. "Image" - "Contrast" p.30
Has color been adjusted appropriately?	Use the "Advanced" menu command to adjust the color. "Image" - "Advanced" p.30

Have the color intensity and tint been adjusted correctly?	Use the "Color Saturation" and "Tint" menu commands to adjust the color and tint.
Only when projecting images from a video source	

■ Images appear dark

Has the image brightness been adjusted correctly?	Use the "Brightness" menu commands to make the adjustments. "Image" - "Brightness" p.30
Has the image contrast been adjusted correctly?	Use the "Contrast" menu command to adjust the color. "Image" - "Contrast" p.30
Is the lamp due for replacement?	When the lamp is nearly due for replacement, the images will become darker and the color quality will become poorer. When this happens, the lamp should be replaced with a new one. \$\sigma\$ p.48

■ Projection stops automatically

Is sleep mode active?	When "Sleep Mode" has been set to On, the lamp turns off
	automatically if no signal is input for about 30 minutes, and the
	projector switches to standby mode. Press the 🕲 button on the
	remote control or the button on the projector's control panel
	to turn the projector's power back on. To cancel the sleep mode
	setting, change "Sleep Mode" menu command to "Off".
	☐ "Settings" - "Sleep Mode" p.33

Problems when projection starts

■ Power does not turn on

Have you pressed the [Power] button?	Press (b) on the remote control or b on the projector's control panel.
Is "Child Lock" set to "On"?	If the "Child Lock" menu command is set to "On", press 🐧 on the projector's control panel for about 3 seconds or press (b) on the remote control to turn the power on. Settings" - "Child Lock" p.33
Is "Control Panel Lock" set to "On"?	If the "Control Panel Lock" menu command is set to "On", all buttons on the projector's control panel are disabled. Press (b) on the remote control. See "Settings" - "Control Panel Lock" p.34
Are all of the indicators switched off?	Disconnect the power cable and then reconnect it. p.14 Check the circuit breaker to see if power is being supplied.
Do the indicators turn off and on when the power cable is touched?	Turn the power off, disconnect the power cable and then reconnect it. If this does not solve the problem, there may be a problem with the power cable. Then contact your local dealer or the nearest address provided in the Support and Service Guide. Epson Projector Contact List



Problems with the remote control

■ The remote control does not work

Is the remote control light- emitting area facing towards the remote control light-receiving area when it is operated?	Face the remote control towards the remote control light-receiving area. Operating range p.13
Is the remote control too far from the projector?	The operating range for the remote control is approximately 10m. p.13
Is direct sunlight or strong light from fluorescent lamps shining onto the remote control light-receiving area?	Set the projector up in a location where strong light will not shine onto the remote control light-receiving area.
Are the batteries dead, or have the batteries been inserted correctly?	Insert new batteries, while making sure that they face correctly. p.13



This section describes maintenance tasks such as cleaning the projector and replacing consumable parts.

Cleaning

You should clean the projector if it becomes dirty or if the quality of projected images starts to deteriorate.



Do not use sprays containing a flammable gas to remove dirt or dust which is adhering to parts such as the lens or filter of the projector. Because the lamp inside the projector becomes very hot during use, the gases may ignite and result in a fire.

Cleaning the air filter


If the air filter becomes blocked with dust and the message "The projector is overheating. Make sure nothing is blocking the air vent, and clean or replace the air filter" is displayed, clean the air filter.

Attention


- If the air filter becomes clogged with dust, it can result in overheating which may cause operating problems or reduce the operating life of the optical parts. It is recommended that you clean the air filter about once every three month. If using the projector in a dusty location, the air filter should be cleaned more often.
- The air filter is not washable. Also do not use detergent or solvents.
- When using a brush for cleaning, use a soft brush with long bristles and brush the filter gently. If you brush too strong, dust may be pushed inside the air filter and hardly be removed.

Remove the air filter cover.

Press the knobs to release the catches, and then pull the cover upward.



2 Take out the air filter.




3 Tap the air filter four or five times with the surface facing downwards to shake off the dust.

Hold the filter at the other side and tap it again to shake off the dust.




Do not hit the air filter hard, otherwise it may become bent or broken and can no longer be used.







4 Use a vacuum cleaner to remove any remaining dust from the surface of the air filter.



5 Install the air filter.




6 Install the air filter cover.



Cleaning the projector case

Clean the projector case by wiping it gently with a soft cloth.

If the projector is particularly dirty, moisten the cloth with water containing a small amount of neutral detergent, and then firmly wring the cloth dry before using it to wipe the projector case. Then wipe the case again with a soft, dry cloth.






Do not use volatile substances such as wax, alcohol or thinner to clean the projector case. These can cause the case to warp and make the coating finish peel off.

Cleaning the lens

To clean the lens it is preferable to use an air blower purchased for the purpose. But alternatively you can wipe it gently clean with a spectacle-cleaning cloth.



Do not rub the lens with harsh materials or subject the lens to shocks, as it can easily become damaged.






Consumable replacement periods

Air filter replacement period

- If the air filter has been broken or the "Replace" message is displayed even though the air filter has been cleaned.
 - Replacing the air filter p.48

Lamp replacement period

• The message "Replace the lamp." appears on the screen when projection starts.



• The projected images get darker or start to deteriorate.



- The replacement warning message is set to appear after a minimum of about 3900 hours of lamp use in order to maintain the initial brightness and quality of the projected images. The time taken for the message to appear will vary depending on usage conditions such as Color Mode settings.
 - If you continue to use the lamp after this period, the possibility of the lamp breaking becomes greater. When the lamp replacement message appears, replace the lamp with a new one as soon as possible, even if it is still working.
- Depending on the characteristics of the lamp and on the way it has been used, the lamp may become darker or stop working before the lamp warning message appears. You should always have a spare lamp ready in case it is needed.
- Contact your local dealer or the nearest address provided in the Epson Projector Contact List.



Replacing consumables

Replacing the air filter

/!\ Caution

Do not touch the lamp cover soon after power-off or you may get burned because it is very hot.



Dispose of used air filters properly in accordance with your local regulations.

Frame material: PP Filter materials: PP, PET Press (b) or ტ to turn off the power, and then turn the main power switch OFF.



Press the knobs to release the catches, and then pull the cover upward.

Replacing the lamp

/!\ Warning

If the lamp stops working and needs to be replaced, there is the danger that the lamp may already be broken. If replacing the lamp of a projector which has been installed to the ceiling, you should always assume that the lamp is broken and handle it with extreme care during removal. Furthermore, you should stand to the side of the projector, not underneath it.



Wait until the lamp has cooled down sufficiently before removing the lamp cover. If the lamp is very hot, you may get burned.

- Press (b) or b turn off the power, and then turn the main power switch OFF.
 - * Wait until the lamp cools down (takes approximately 1 hour).
- Securely tighten the lamp fixing screws.

Insert the supplied screwdriver of the replacement lamp into the lamp cover opening switch, then remove the lamp cover.



Install the lamp cover.



Resetting the lamp operating time

The lamp operating time must always be reset after the lamp has been replaced with a new one.

The projector has a built-in counter which keeps track of the lamp operating time. When the cumulative operating time reaches a certain point, it causes the replacement warning message to be displayed.

Press (b) to turn on the power.

Press Menu to display the configuration menu.





Remove the old air filter.



4 Insert the new air filter.




Install with the groove faced to the right.

5 Install the air filter cover.



3 Loosen the lamp fixing



4 Remove the old lamp.



Pull out straight.

Insert the new lamp.



Make sure that it faces the correct way.

Attention

- Install the lamp and the lamp cover securely. The projector will not turn on if the lamp or the lamp cover is not installed correctly.
- This product includes a lamp component that contains mercury (Hg). Please consult your local regulations regarding disposal or recycling. Do not dispose of it with normal waste.

Select "Reset Lamp Hours" from the "Reset" menu.



Select "Yes" and then press (Enter).



Appendix

Optional Accessories/Consumables



The following optional accessories/consumables are available for purchase if required. This list of optional accessories/consumables is current as of: 2010.7. Details of accessories are subject to change without notice.

Varies depending on country of purchase.

■ Optional Accessories

50" Portable Screen ELPSC06

A compact screen which can be carried easily. (Aspect Ratio → 4:3)

60" Portable Screen	ELPSC07
80" Portable Screen	ELPSC08
100" Portable Screen	ELPSC10

A portable roll-type screen. (Aspect 4:3)

VGA-HD15 PC Cable (1.8 m)	ELPKC02
VGA-HD15 PC Cable (3 m)	ELPKC09
VGA-HD15 PC Cable (20 m)	ELPKC10

(For mini D-Sub 15-pin/mini D-Sub 15-pin) Use to connect the projector to a computer.

Ceiling Mount*	ELPMB20
	ELPMB22

(with ceiling plate)

Use when installing the projector to a ceiling.

Ceiling Pipe 600 (600 mm/white)*	ELPFP07
Ceiling Pipe 450 (450 mm/white)*	ELPFP13
Ceiling Pipe 700 (700 mm/white)*	ELPFP14

Use when installing the projector to a high ceiling or a ceiling with veneer panels.

Cable Cover (White) ELPCC01W

Use to cover cables of the projector that is suspended from a ceiling to improve the appearance.

* A special method of installation is required in order to suspend the projector from the ceiling. Please contact the place of purchase if you would like to use this installation method.

■ Consumables

Lamp Unit	ELPLP49
-----------	---------

(1 spare lamp, 1 spare screwdriver) Use as a replacement for spent lamps.

Air Filter Set	ELPAF21
----------------	---------

(1 air filter)

Use as a replacement for old air filters.

List of Supported Monitor Displays



Component Video

Signal	Refresh rate (Hz)	Resolution (Dots)
<u>SDTV</u> → (480i)	60	720×480
SDTV(576i)	50	720×576
SDTV(480p)	60	720×480
SDTV(576p)	50	720×576
<u>HDTV</u> → (720p)	50/60	1280×720
HDTV(1080i)	50/60	1920×1080
HDTV(1080p)	50/60	1920×1080

Composite Video»/S-Video»

Signal	Refresh rate (Hz)	Resolution (Dots)
TV(<u>NTSC</u> [▶])	60	720×480
TV(<u>SECAM</u> [▶])	50	720×576
TV(<u>PAL</u> [▶])	50/60	720×576



Input signal from the [HDMI1] / [HDMI2] input port

Signal	Refresh rate (Hz)	Resolution (Dots)
<u>VGA</u> ▶	60	640×480
<u>SDTV</u> → (480i)	60	720×480
SDTV(576i)	50	720×576
SDTV(480p)	60	720×480
SDTV(576p)	50	720×576
<u>HDTV</u> → (720p)	50/60	1280×720
HDTV(1080i)	50/60	1920×1080
HDTV(1080p)	24/30/50/60	1920×1080

Computer image (analog RGB)

Signal	Refresh rate (Hz)	Resolution (Dots)
<u>VGA</u> →	60/72/75/85	640×480
SVGA [▶]	56/60/72/75/85	800×600
XGA →	60/70/75/85	1024×768
	70/75/85	1152×864
<u>SXGA</u> [▶]	60/75/85	1280×960
	60/75/85	1280×1024
WXGA	60	1280×768
	60	1360×768
	60/75/85	1280×800
MAC13"	67	640×480
MAC16"	75	832×624
MAC19"	59/75	1024×768
MAC21"	75	1152×870

Specifications



Product name Dimensions Panel size Display method Resolution	d Digital	Pol	(H) × 360 (0.74 in	EH-TW3200 (D) mm (not including feet) sch wide		
Panel size Display method		Pol	0.74 in			
Display method				ch wide		
				0.74 inch wide		
Resolution	Digital	2.073.600 pi	Polysilicon TFT active matrix			
	Digital	1 2,075,000 pm	2,073,600 pixels (1920 (W) × 1080 (H) dots) × 3			
Scanning	Digital	Pixel clock: 13.5 to 148.5 MHz				
frequencies		Horizontal: 15.63 to 67.5 kHz				
		Vertical: 24, 50 to 60 Hz				
	Analogue	Pixel clock: 13.5 to 157.5 MHz				
		Horizontal: 15.63 to 91.15 kHz				
		Vertical: 50 to 85 Hz		85 Hz		
Focus adjustment		Manual				
Zoom adjustment		Manual (Approx. 1 : 2.1)				
Lens shift		Manual (Maximums: Approx. 96% vertically, 47% horizontally)				
Lamp (light source)		UHE lamp, 200 W, Model No.: ELPLP49				
Power supply		100 to 240V AC±10%, 50/60Hz, 3.1 to 1.3A				
Power	100 to 120V	Operating: 272W		ng: 272W		
Consumption	area	Standby: 0.2W				
	220 to 240V	Operating: 261W				
	area	Standby: 0.3W				
Operating altitude		0 to 2286m				
Operating temperature		+5 to +35°C (No condensation)				
Storage temperature		-10 to +60°C (No condensation)				
Mass		Approx. 7.3kg				
Ports		Component input	1	RCA pin jack × 3		
		PC input	1	Mini D-sub 15-pin (female) blue		
		HDMI input*	2	HDMI** HDCP compatible, incompatible with CEC signals		
		Video input	1	RCA pin jack		
		S-Video input	1	Mini DIN 4-pin		
		RS-232C	1	D-sub 9-pin (male)		
		Trigger out	1	3.5 mm mini jack		

^{*} You can connect any HDMI or DVI-D compatible equipment. However, depending on the equipment, the projector may not project any image.





pixelworks Pixelworks DNXTM ICs are used in this Projector.

This product is also designed for IT power distribution system with phase-to-phase voltage 230V.

Product Information


Türkiye'deki kullanıcılar icin

For users in Turkey:

EEE Yönetmeliğine Uygundur.

In Conformity with the Turkish EEE Regulation.

■ Angle of tilt




If you set the projector higher than 8°, it could damage the projector and cause an accident.

■ RS-232C cable layout

• Connector shape: D-Sub 9-pin (male)

• Projector input connector: RS-232C



>	Signal	Function	
	GND	Signal wire earth	
	TD Transmit data		
	RD	Receive data	



DECLARATION of CONFORMITY

According to 47CFR, Part 2 and 15 Class B Personal Computers and Peripherals; and/or CPU Boards and Power Supplies used with Class B Personal Computers

We: EPSON AMERICA, INC. Located at: 3840 Kilroy Airport Way

MS: 3-13

Long Beach, CA 90806

Tel: 562-290-5254

Declare under sole responsibility that the product identified herein, complies with 47CFR Part 2 and 15 of the FCC rules as a Class B digital device. Each product marketed, is identical to the representative unit tested and found to be compliant with the standards. Records maintained continue to reflect the equipment being produced can be expected to be within the variation accepted, due to quantity production and testing on a statistical basis as required by 47CFR 2.909. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Trade Name: EPSON

Type of Product: LCD Projector Model: H373C/H416C

FCC Compliance Statement For United States Users

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

WARNING

The connection of a non-shielded equipment interface cable to this equipment will invalidate the FCC Certification or Declaration of this device and may cause interference levels which exceed the limits established by the FCC for this equipment. It is the responsibility of the user to obtain and use a shielded equipment interface cable with this device. If this equipment has more than one interface connector, do not leave cables connected to unused interfaces. Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

Glossary



Following is an explanation of some of the terms used in this guide which may be unfamiliar or which were not explained in the manual itself. Further information can be obtained by referring to other commercially-available publications.

Aspect Ratio

The ratio between an image's length and its height. Wide screen refers to screens such as those for HDTV where the ratio between the width and the height is 16:9. The aspect ratio for SDTV and general computer screens is 4:3.

Component video

A method of separating images signals into luminance (Y), blue color difference (Cb or Pb) and red color difference (Cr or Pr) for video transmission.

Composite video

A video transmission method conveying luminance and chrominance signals together in a single cable.

Contrast

The relative brightness of the light and dark areas of an image can be increased or decreased in order to make text and graphics stand out more clearly, or to make them appear softer.

Cool-down

This is the process by which the projector's lamp is cooled down after it has become hot through use. It is carried out automatically when the [Power] button on either the remote control or the projector's control panel has been pressed to turn off the projector. Do not turn off the main power switch while cool-down is in progress, otherwise the cool-down process will not work properly. If the cool-down period is not allowed to finish normally, the projector's lamp and internal components will remain at high temperatures, and this may shorten the useful life of the lamp or cause problems with the operation of the projector. The projector takes about 16 seconds to cool down. The actual time will vary depending on the external air temperature.

HDCP

An abbreviation for High-bandwidth Digital Content Protection, which is a type of copyright protection technology used for preventing unauthorized copying by encoding digital signals which are transmitted and received via DVI and HDMI ports. The HDMI input terminals of this projector are HDCP compatible, so that digital images which are protected by HDCP technology can be projected. However, if changes are made to the HDCP standard, it may no longer be possible to project digital images which have been protected by the new, changed standard.

$HDMI^{TM}$

An abbreviation for High Definition Multimedia Interface, and refers to a standard for digital transmission of high-definition images and multi-channel audio signals.

HDMITM is a standard that is targeted towards household digital equipment and computers that allows digital signals to be transmitted in their original high quality without compression, and it also includes a digital signal encryption function.

HDTV

An abbreviation for High-Definition Television. It refers to high-definition systems which satisfy the following conditions.

- Vertical resolution of 720p or 1080i or greater (p = progressive → , i = interlace →)
- Screen aspect of 16:9
- Dolby Digital audio reception and playback (or output)

Interlace

Displays an image by transmitting scan data for every other line from top to bottom. Because one frame is displayed in every other line, flickering may easily become visible.

NTSC

An abbreviation for National Television Standards Committee, and a format for ground-based analogue color television broadcasts. This format is used in Japan, North America and Central and South America.

PAL

An abbreviation for Phase Alternation by Line, and a format for ground-based analogue color television broadcasts. This format is used in Western European countries except France, and also in Asian countries such as China and in Africa.

Progressive

Displays an image for one frame line by line from top to bottom all at once. Even though the scanning lines are the same as for interlace scanning, flickering is much less visible in images because twice as much information transmitted per unit time.

S-Video

A method of separating images signals into luminance (Y) and chrominance (C) for video transmission.

SDTV

An abbreviation for Standard Definition Television. It refers to standard television systems which do not satisfy the conditions for HDTV.



SECAM

An abbreviation for Sequential Couleur A Memoire, and a format for ground-based analogue color television broadcasts. This format is used in France, Eastern Europe and the former Soviet Union, the Middle East and Africa.

Security lock

A device consisting of a protector case with a hole in it that a commercially-available theft-prevention cable can be passed through in order to secure the device to a table or pillar. This projector is compatible with the Microsaver Security System manufactured by Kensington.

SVGA

A screen resolution standard for 800(W) x 600(H) pixels.

SXGA

A screen resolution standard for 1280(W) x 1024(H) pixels.

Sync. (Synchronization)

The signals output from computers have a specific frequency. If the projector frequency does not match this frequency, the resulting images will not be of a good quality. The process of matching the phases of these signals (the relative position of the crests and troughs in the signal) is called "synchronization". If the signals are not synchronized, problems such as flickering, blurriness and horizontal interference can occur.

Tracking

The signals output from computers have a specific frequency. If the projector frequency does not match this frequency, the resulting images will not be of a good quality. The process of matching the frequency of these signals (the number of crests in the signal) is called "tracking". If tracking is not carried out correctly, wide vertical stripes will appear in the projected images.

VGA

A screen resolution standard for 640(W) x 480(H) pixels.

XGA

A screen resolution standard for 1024(W) x 768(H) pixels.

YCbCr

A component video signal for SDTV. Y indicates the luminance, and Cb and Cr indicate the color difference.

YPbPr

A component video signal for HDTV. Y indicates the luminance, and Pb and Pr indicate the color difference.



Numeric Character	HDMI Video Range	28,	33
	HDTV		
2-2 Pull-down	High Altitude Mode		
Α	Hue, saturation, and brightness adjustment	••••	. 20
Abs. Color Temp	П		
Advanced			
Air filter	Illumination		
Aspect	"Image" menu		
Auto	Image size		
Auto Iris	Indicators	,	
Auto Setup	"Info" menuInput Signal		
_	Input Signai	29,	33
В			
Battery replacement period (Remote control)		6	10
Brightness	Lamp CoverLamp Hours		
-	Lamp HoursLamp Hours		
C	Lens cover		
Ceiling 11, 29, 34	Lens shift		
Child Lock	Line menu		
Cleaning the air filter	Load Memory		
Cleaning the lens	======================================	,	
Cleaning the projector case	M		
Color Mode		1.4	15
Color Saturation	Main power switch8,		
Component input port	Memory" "Memory" menu		
Component Video	Menu Color		
Composite Video	Menu Position		
Configuration menu	Menus		
Connecting to a computer	Messages		
Connecting to a video source	Motion Detection		
Consumables		,	
Contrast	N		
Control Panel 6	Noise Reduction	28	32
Control Panel Lock 29, 34	Normal		
Cool-down	Normar		1)
Correcting projector tilt	0		
		22	20
D	Offset		
Direct Power On	Optional accessories		
Display	Overheating		
Display Background	Overscan	۷٥,	33
а	P		
3		50	52
Epson Cinema Filter	PC input port		
EPSON Super White	Port		
Erase Memory	Position Power cable		
	Power Consumption		
6	Power inlet		
Focus adjustment	Progressive		
Front adjustable foot	Projection11,		
Full	Projection distance		
Full Menu	Projection image position adjustment		
_	Projection methods		
G	. J 		
Gain	R		
Gamma	Refresh Rate		20
	Remote control		
	Replacing the air filter		
HDMI input port	Replacing the battery		
	replacing the battery		13



Replacing the lamp		48
Reset		
Reset All	,	
Reset Lamp Hours		
Reset Memory		
"Reset" menu		
Resolution	,	
RGB		
RGBCMY		
RS-232C		54
RS-232C port	8,	53
S		
Save Memory	24,	29
Screen size		
SDTV		
Selecting the image source		
"Settings" menu		
Setup Level		
Sharpness		
Sharpness (Advanced)		
"Signal" menu		
Skin Tone		
Sleep Mode		
Source		
Specifications		
Startup Screen		
Sub-menu		
Supported Monitor Displays		
S-Video		
S-Video input port		
Sync Info		
Sync inio		
Sync.		
Sync.		
Sync.		
	28,	31
Test Pattern	28,	3117
Test Pattern	28, 28,	311730
Test Pattern	28, 28,	31 17 30 .26
Test Pattern Tint Top menu Tracking	28, 28, 28,	17 30 .26 31
Test Pattern Tint Top menu Tracking Trigger Out	28, 28, 28, 28,	17 30 26 31 34
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port	28, 28, 28, 28, 29, 8,	17 30 .26 31 34 53
Test Pattern Tint Top menu Tracking Trigger Out	28, 28, 28, 28, 29, 8,	17 30 .26 31 34 53
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port	28, 28, 28, 28, 29, 8,	17 30 .26 31 34 53
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off	28, 28, 28, 8, 	17 30 26 31 34 53 15
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off	28, 28, 28, 8, 	17 30 26 31 34 53 15
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off	28, 28, 28, 8, 	17 30 26 31 34 53 15
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off U Using the configuration menus	 228, 228, 229, 8, 	17 30 26 31 34 53 15
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off U Using the configuration menus V Video input port 8, 12, 5	228, 228, 229, 8, 	31 17 30 26 31 34 53 15
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off U Using the configuration menus	228, 228, 229, 8, 	31 17 30 26 31 34 53 15
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off U Using the configuration menus V Video input port 8, 12, 5	228, 228, 229, 8, 	31 17 30 26 31 34 53 15
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off. U Using the configuration menus V Video input port Video Signal W	28, 28, 29, 8, 	31 17 30 26 31 34 53 15 26
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off. U Using the configuration menus V Video input port Video Signal	28, 28, 28, 28, 51,	31 17 30 26 31 34 53 15 .26
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off. U Using the configuration menus V Video input port Video Signal W Warning indicator Wide	28, 28, 28, 28, 51,	31 17 30 26 31 34 53 15 .26
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off U Using the configuration menus V Video input port Video Signal W Warning indicator	28, 28, 28, 28, 51,	31 17 30 26 31 34 53 15 .26
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off. U Using the configuration menus V Video input port Video Signal W Warning indicator Wide	28, 28, 28, 51,	31 17 30 26 31 34 53 15 26 53 29
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off. U Using the configuration menus V Video input port Video Signal W Warning indicator Wide X x.v.Color	28, 28, 28, 51,	31 17 30 26 31 34 53 15 26 53 29
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off. U Using the configuration menus V Video input port Video Signal W Warning indicator Wide	28, 28, 28, 51,	31 17 30 26 31 34 53 15 26 53 29
Test Pattern Tint Top menu Tracking Trigger Out Trigger out port Turning off. U Using the configuration menus V Video input port Video Signal W Warning indicator Wide X x.v.Color	28, 28, 28, 51, 4,	31 17 30 26 31 34 53 15 26 53 29 37 19

Z	
Zoom	19
Zoom adjustment	6, 16
Zoom Caption Pos	19, 28, 31
Zoom Size	28, 31



All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or otherwise, without the prior written permission of Seiko Epson Corporation. No patent liability is assumed with respect to the use of the information contained herein. Neither is any liability assumed for damages resulting from the use of the information contained herein.

Neither Seiko Epson Corporation nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties as a result of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or (excluding the U.S.) failure to strictly comply with Seiko Epson Corporation's operating and maintenance instructions.

Seiko Epson Corporation shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Epson Products or Epson Approved Products by Seiko Epson Corporation.

The contents of this guide may be changed or updated without further notice.

Illustrations and screens used in this publication may differ from actual illustrations and screens.

General Notice:

"x.v.Color" and x.v.Color are trademarks of Sony Corporation.

Macintosh, Mac, and iMac are trademarks of Apple Inc.

Dolby is a trademark of Dolby Laboratories.

HDMI and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC.

Pixelworks and DNX are trademarks of Pixelworks, Inc.

Other product names used herein are also for identification purposes only and may be trademarks of their respective owners. Epson disclaims any and all rights in those marks.